



FS-Tools Help File
ES-50X
ES-50XC
Programming Guide



Table of Contents

Welcome to FS-Tools	1
FS-Tools Features	1
Software Downloads	1
Installing FS-Tools	2
Complete Setup versus Custom Setup	2
Installation	2
System Requirements	9
Uninstalling FS-Tools	10
Getting Started	11
Logging On.....	11
Exiting.....	11
Customer Screen.....	12
Adding a New Customer	13
Duplicating a Customer Record	14
Finding a Customer	15
Editing Customer Details.....	15
Configuring a Fire Panel for a Customer.....	15
Deleting a Customer Record	16
Configuring the Fire Panel	17
Selecting Configuration Type.....	17
Configuring System Info.....	18

Communicator Settings	19
Central Station	19
Gains Settings	20
Test Times.....	20
Central Station Event Codes.....	21
Primary/Secondary Central Station	22
Central Station Settings	23
Input/Output.....	24
Relays/Zones	24
Relays	25
Zones	25
Special Zones.....	26
NACs	27
NAC Features	28
NAC Synchronization Types	28
NAC Zone Mapping	28
General System Settings.....	29
Timers.....	30
Daylight Savings Time.....	31
Clock Format	31
Loop Style	31
Protocol Type	31

Language Support.....	32
Aux Settings.....	32
Banner Display	32
ANN-Bus Settings.....	32
Global Options	32
ANN-Bus Guidelines	34
Primary/Secondary ANN Bus	34
ANN-S/PG Options	35
ANN-LED Options	35
ANN-80 Options	36
Primary/Secondary ANN-Bus.....	37
ANN-I/O	38
ANN-I/O Point Option	38
ANN-I/O Zone Option	40
ANN-(R)LED	41
ANN-LED Point Option	42
Alarm Only (for use with ANN-RLED module)	42
Alarm, Trouble and Supervisory.....	43
ANN-LED Zone Options.....	44
Alarm Only (for use with ANN-RLED module)	44
ANN-LED Zone Option - Alarm, Trouble and Supervisory	45
ANN-RLY.....	46

Function Keys	47
Function Key Zone Select	48
Function Key NAC Select.....	49
SLC Loop Set-up.....	49
SLC Loop.....	49
Loop Style	49
Detectors	49
Adding Devices.....	50
Viewing Devices.....	51
Editing Devices.....	52
Deleting Devices.....	53
Finding Devices.....	54
Device Address.....	54
Detector Device Type	55
Detector Device Options.....	56
Sounder Base Options.....	57
Wireless Option	57
Modules	58
Adding Devices.....	59
Viewing Devices.....	60
Editing Devices.....	61
Deleting Devices.....	62
Finding Devices.....	63

Device Address.....	63
Module Device Type	64
Monitor Module Types	64
Control Module Types	66
Module Device Options.....	66
Wireless Option	67
Verify Setup.....	67
Simulation	69
Tabular View.....	69
Graphical View.....	71
Upload Information.....	72
Walktest Data	73
History Data	74
System Status Data	75
File Menu	76
Changing Download Password	76
Template Menu.....	77
Delete a Template.....	77
Tools Menu.....	78
Compare Configuration.....	79
Database Backup.....	79
Restore Backup	80

Export a Configuration	81
Export to Excel	81
Export to Disk	82
Import a Configuration.....	83
Import All Configurations.....	84
Get Write Access	85
Modifying Customer Details	85
Run from Database.....	86
To Connect to the Server Database.....	86
To Connect to the Client Database	87
Last Configuration Date	87
Upload/Download Menu	88
Upload/Download Configuration Data.....	88
Upload/Download	88
Download Configuration Data to the FACP.....	88
Upload Configuration Data from the FACP	94
Connection Settings	96
USB Connection Settings	96
Thumb Drive Upload/Download.....	97
Transfer Database To Flash Drive	97
Transfer Database From Flash Drive	99

Configuring Reports.....	100
Configuring NFPA Reports.....	100
Record of Completion	101
Protected Site Information	102
Fire Alarm System Information	103
Type of Fire Alarm System or Service	105
System Software	106
Signaling Line Circuit	107
Manual and Automatic Initiating Devices and Circuits	107
Supervisory Signal	109
Annunciators	111
Alarm Notification Devices and Circuits	112
System Power Supply	114
Record of System Installation and System Operation.....	115
Certifications and Approvals	116
Configuring Inspection and Testing	117
General Information	118
Type Transmission	120
Signaling Line Circuit	121
Alarm Initiating Devices and Circuit Information	121
Alarm Notification Appliances	123
Supervisory Signal - Initiating Devices and Circuit Information ..	124

System Power Supplies.....	126
Notifications Prior to Testing	128
System Tests and Inspections	129
Secondary Power.....	130
Combination Systems.....	131
Emergency Communication Equipment.....	132
Supervising Station Monitoring.....	133
Notifications and Approvals.....	134
Upload Information.....	136
Device Maintenance Information	136
Reports Menu.....	139
Configuration Data Report.....	139
Central Station Report	140
Generate as PDF	140
Generate as Excel File	141
NFPA Report	142
Record of Completion Report	142
Generate as PDF.....	142
Generate as Excel File	143
Generate as Word Document	144
Inspection and Testing Report.....	145
Generate as PDF.....	145

Generate as Excel File	146
Generate as Word Document	147
Troubleshooting	148
Panel Connection Lost	148
FS-Tools Failed to Download Data to Panel	149
FS-Tools Failed to Upload Data from Panel	150
Verify Secret Code Request Denied	151
Other Events	152
Contact Us	153
Documentation Feedback	153
Technical Support	153
Index	154

Welcome to FS-Tools

FS-Tools lets you create and edit databases used to program fire panels and related fire system equipment. With the integrated Upload/Download facility, you can use it to configure fire panel settings and download it to the panel. Various information can also be uploaded from the panel to FS-Tools.

FS-Tools Features

- [Maintains details](#) of the fire panel customers
- [Configures fire panel settings](#) for a customer
- [Verify Setup](#) feature verifies configuration settings before downloading to panel
- [Download Utility](#) to download the configuration information to the fire panel
- [Upload Utility](#) to upload event logs, history data, and troubleshoot data from the fire panel
- [File Comparison Utility](#) allows location by location comparison of separate upload and download files
- [Export Configuration](#) feature to export the saved configuration to a file
- Graphical representation of installed [detectors](#) and [modules](#)
- [Simulation feature](#) displays the correlation of the input and output devices
- Fire panel troubles and events [troubleshooting](#)

Software Downloads

In order to supply the latest features and functionality in fire alarm and life safety technology to our customers, we make frequent upgrades to the embedded software in our products. To ensure that you are installing and programming the latest features, we strongly recommend that you download the most current version of software for each product prior to commissioning any system. Contact Technical Support with any questions about software and the appropriate version for a specific application.

Installing FS-Tools

Complete Setup versus Custom Setup


FS-Tools setup offers two installation options.

- **Complete Setup (default)** installs both the FS-Tools Client and Server. The Complete setup is used in stand-alone applications. In a stand-alone application, the FS-Tools Client and Server are installed on the same computer.
- **Custom Setup** can be used for installing either the FS-Tools Client or the FS-Tools Server. The Custom setup is typically used in network applications. In a network application, the FS-Tools Server (database) is installed at a central location. Multiple users (FS-Tools Client) can access customer records from the FS-Tools Server.


Installation

To install FS-Tools:

1. Run **FS-Tools Setup.exe**. The **FS-Tools - InstallShield Wizard** screen appears.




2. Click **Next**. The **Destination Folder** screen appears. By default, the destination folder is **C:\Program Files\Honeywell\FS-Tools**.




3. If desired, click **Change** to change the destination folder. Locate the folder where you want to install FS-Tools, and Click **OK**.
4. Click **Next** to continue with the installation.
5. If a database of a previously installed FS-Tools exists, a message indicating the folder path of the database appears. Click **OK** to continue.



6. The **Create new download password** screen appears. Type the download password in **Password** and then retype the password in the **Confirm Password** box. The password must be at least 6 characters long.




7. Click **Next**. The **Setup Type** screen appears. Review Setup Types.




[\(Skip to Network Setup\)](#)

For Standalone Setup:

8. Select *Standalone* to install both the FS-Tools Client and Server. Click **Next**. The **Ready to Install** screen appears.




9. Click **Finish** after the installation is complete to close the **FS-Tools - Installation Wizard**.




For Network Setup:


9. In the **Setup Type** screen, select **Network** setup to install only the FS-Tools Client. Click **Next**. The **Custom Setup** screen appears.



10. In the **Custom Setup** screen, select the option in the Server list to disable the FS-Tools Server, to install only the FS-Tools Client. Click **Next**.




11. The **Database Server Information** screen appears.




12. Select/type the IP address of the FS-Tools Server from the **Database Server** drop-down list. Click **Next**.

13. The **Ready to Install** screen appears. Click **Install**.



14. A screen indicating the installation progress appears.

15. Click **Finish** after the installation is complete to close the **FS-Tools - Installation Wizard**.



Windows Vista Users

If you want to install or upgrade FS-Tools in a Windows Vista operating system, the User Account Control (UAC) feature needs to be turned off.

To turn off the UAC:

1. Click **Start > Control Panel**. The **Control Panel** window appears.
2. In the **Control Panel** window, click **User Accounts**.
3. In the **User Accounts** window, click **User Accounts**.
4. On the right page of the User Accounts window, click **Turn User Account Control on or off**.
5. If the UAC is currently configured in Admin Approval Mode, the **User Account Control** message box appears. Click **Continue**. The **Turn User Account Control on or off** window appears.
6. Clear the **Use User Account Control (UAC) to help protect your computer** check box and then click **OK**. A message box appears.
7. Click **Restart Now** to apply the change immediately or click **Restart Later**, and then close the User Accounts tasks window.
8. Install FS-Tools.
9. Turn the UAC back on by reversing the steps above.

System Requirements


Before you begin the setup process, ensure that your laptop or computer has the minimum hardware, software, and support components.

Component	Requirement
Operating System	Windows XP, Windows Vista, Windows7, Windows 8, Windows 8.1, Windows 10 with Microsoft® Excel software
Processor	16 GHz P4 Processor
RAM	Minimum 256MB
Cache	512K
Hard Disk Drive	20GB with a minimum of 1GB available
Graphics Card and Monitor	1024 x 768 pixel resolution or higher
Color Palette	256 colors, True Color, Font size: small or large
Communication	USB Drive
Printer	HP LaserJet

Uninstalling FS-Tools

FS-Tools can be uninstalled using the Control Panel.

1. Click **Start**, and then choose **Control Panel**. The **Control Panel** window appears.
2. Double-click **Programs and Features**.
3. From the list of installed programs, select FS-Tools.
4. Click **Uninstall**. A message asking for your confirmation appears.
5. Click **Yes**. The FS-Tools application is uninstalled.



Note: Uninstalling FS-Tools removes the FS-Tools software but not the database. You must delete the database manually by navigating to the installed location and deleting the database folder. FS-Tools software will not work correctly if you install a later version of FS-Tools software without deleting the previous version database.

Getting Started

Logging On

To log on to FS-Tools:


Click **Start**, and then choose **Programs > FSTools > FS-Tools**.

Or



Double click the icon on the desktop.

The initial customer details window appears.



The screenshot shows the FS-Tools application window. The top menu bar includes File, Template, Tools, Upload/Download, Reports, and Help. Below the menu is a toolbar with buttons for New Customer, Download, Configure, and Delete. A search bar is also present. The main area is divided into two sections. The top section, titled 'Customer List', contains a table with columns for First Name, Last Name, Address 1, Address 2, City, State, Zip Code, Contact Number, Panel Type, and Version. The bottom section, titled 'New Customer', contains a form for entering customer details. The form includes fields for First Name, Last Name, Address 1, Address 2, City, State, Zip Code, Contact Number, and Panel Type. A 'Version' dropdown menu is set to '1.0'. At the bottom of the form, there is a 'Please enter details for new customer...' message and buttons for 'OK' and 'Cancel'.

On this screen, you can add a customer, select their panel type, and then begin to configure the fire system.

Exiting

To exit the FS-Tools application, click  on the upper-right corner of the window

Or

Click **Exit** from the **File** menu.

Customer Screen

Using FS-Tools, you can configure the settings of the 50 Point Addressable Fire Alarm Control Panel (FACP and in addition, maintain the details of the fire panel customers.

Before you can configure the fire panel settings, you need to add the customer information to the FS-Tools database. Customer details such as First Name, Last Name, Address, Contact Number, and Panel Type (panel version must be added).

When you log on to FS-Tools, the customer screen appears. This screen consists of the **Customer List** and the **Customer Details** sections. The **Customer List** section displays the list of existing customers for the fire panel and the **Customer Details** section displays the details for a selected customer. Upon first login of the application, the **Customer List** section will be empty. The **Customer Details** section will display **New Customer**, prompting an entry into the database.

The initial customer screen in FS-Tools allows you to:


- [Add a new customer.](#)
- [Find an existing customer.](#)
- [Select and configure a fire panel for a customer.](#)
- [Edit customer details.](#)
- [Delete a customer record.](#)

Adding a New Customer

A new customer can be the protection services staff for campuses such as museums, universities, or schools, where the 50 Point Addressable Fire Alarm system is installed. Details such as First Name, Last Name, Address, etc. can be added for each customer.

To enter new customer details:

1. Click **New Customer**.
2. Fill out the First Name, Last Name, Address 1, Address 2, City, State, Zip Code, and Contact Number fields for the customer. Fields marked with * are mandatory.
3. Select the appropriate fire panel type from the drop-down box.
4. Click **Save**. A confirmation message appears.




5. Click **Yes**. The details for the new customer are added in the FS-Tools database.

Duplicating a Customer Record


You can also add a new customer in FS-Tools by making a copy of an existing customer record and modifying the information.

To duplicate a customer record:

1. Select the customer record and click **Duplicate**. A confirmation message appears.
2. Click **Yes** in the confirmation message to proceed.



3. If configuration settings exist for the selected customer, another confirmation will appear. To duplicate the configuration information along with the customer record, click **Yes** in the Duplicate Customer dialog box. To duplicate only the customer record, click **No**.




Finding a Customer

Using the **Find** option you can find the details for a customer when there are multiple customer records. You can search by the First Name, Last Name, Address 1, Address 2, City, State, Zip Code, or the Contact Number. The **Search** results are displayed in the **Customer List** section.

To find a customer:

1. In the **Find** list, select the field for the search. Options include First Name, Last Name, Address 1, Address 2, City, State, Zip Code, Contact Number, Panel Type, or Version,
2. In the text box provided, type the keyword for the search.
3. Click **Search**. The search results are displayed in the **Customer List**.



To retrieve all customer records, click **Show All**. All the customer records are retrieved in the Customer List.

Editing Customer Details

You can update all the customer details using the **Edit** option.

To edit the customer details:

1. Select the customer record you want to edit. You may want to use the **Find** option.
2. Update the customer data in the **Customer Details** section.
3. Click **Save**. If you select another customer record without saving, you are prompted to save the updated record.
4. Click **Yes** to update the customer details in FS-Tools.

Configuring a Fire Panel for a Customer

Using the **Configure** option, you can configure all the fire alarm system settings. Before you configure the fire panel, new customer details must be added to the FS-Tools database.

To configure the fire panel for a customer:


1. Using the **Find** option, select the customer record.
2. Click **Configure**.
For more information about configuring the fire panels, [click here](#).

Deleting a Customer Record


When a customer account is considered inactive, you can delete the customer record. The saved configuration information for the fire panel also gets deleted when you delete a customer record.

To delete a customer record:

1. Select the customer record you want to delete. You may want to use the **Find** option.
2. Click **Delete**. A message asking for confirmation appears.



3. Click **Yes** to delete the customer record. If configuration settings exist for the customer record, a message asking for confirmation to delete the configuration information is displayed. The following screen appears:



4. To delete the customer record along with the configuration information, click **Yes**.

Configuring the Fire Panel


Using FS-Tools, you can configure fire panel settings. This involves:

- configuring the settings for input and output modules.
- configuring the fire panel settings such as date and time, banner display, fire panel passwords, etc.
- configuring the SLC loop setup for the detectors and modules.
- verifying the SLC loop setup.
- simulating the setup to evaluate SLC loop.
- modifying the customer details in the server.

After you configure the fire panel settings, you must connect the computer to the fire panel and download the configuration settings. In addition, you can upload the configuration information from the fire panel, and view the fire alarm system settings in FS-Tools.

Selecting Configuration Type

1. Using the **Find** option from the initial screen, if necessary, select a customer record. For more information, see [Finding a Customer](#).
2. Click **Configure** to program the fire panel settings. The **Configuration Type** dialog box appears.



3. In the **Select Configuration** list select the default option *Factory Default*, if you are configuring for the first time or select a previously saved configuration which appears in the list.
4. Click **OK**. The **System Info** programming page appears.

Configuring System Info

In FS-Tools, configuring the system information involves the following steps:

1. Configuring the communicator settings:
 - a. [Central Station](#)
 - b. [Primary Central Station](#)
 - c. [Secondary Central Station](#)
2. Configuring the input/output modules:
 - a. [Relays](#)
 - b. [Zones](#)
 - c. [Special Zones](#)
 - d. [NACs](#)
3. Configuring the [general system settings](#) which include the timers, clock format, trouble reminder, and other settings
4. Configuring the [ANN-Bus](#), Primary and Secondary
5. Editing the [Function Keys](#)' actions.
6. Configuring the SLC Loop Setup:
 - a. [Detectors](#)
 - b. [Modules](#)

Communicator Settings

Central Station

The optional IP/POTS Communicator card transmits system status (alarms, troubles, AC loss, etc. to a Central Station via the public switched telephone network and via an ethernet connection.

In FS-Tools, you must enable reporting from the communicator to report the fire alarm system status, alarm, and trouble conditions to the central station. The **System Info -> Communicator Settings -> Central Station** pane appears after you select the configuration type.

Note: All programming features may not be applicable to the your panel's version of software.

See the following pages to learn more.

System Info -> Communicator Settings -> Central Station

IP/CELLULAR Settings

Supervision: **ALARMNET 2010 IP + CELLULAR**

POTS Settings

Phone Line 1 Settings

Enabled ☒ Disabled ☐

Supervision: Enabled ☐ Disabled ☒

TouchTone/Rotary: Touch Tone ☒ Rotary 67/33 ☐ Rotary 60/40 ☐

Phone Line 2 Settings

Enabled ☒ Disabled ☐

Supervision: Enabled ☐ Disabled ☒

TouchTone/Rotary: Touch Tone ☒ Rotary 67/33 ☐ Rotary 60/40 ☐

GAIN Settings

Dialing Gain: **NORMAL**

Reporting Gain: **NORMAL**

Test

Time Interval: **24 Hours**

Start Time: **01:00** (24 Hr.)

IP Settings

☒ DHCP Enabled

Supervision: **ALARMNET 2010 IP**

IP Address:

Subnet Mask:

Gateway Address:

DNS Address:

EVENT CODES

ADEMCO CONTACT ID: **SIA 8/SIA 20**

Event Code	Value
Pull Station	115
User Defined Monitor 1	115
Waterflow	113
User Defined Monitor 2	113
Smoke (Photo)	111
User Defined Detector 1	111
Smoke (Ion)	111
User Defined Detector 2	111
Heat Detect	114
User Defined Detector 3	114
Smoke Duct Photo	116
User Defined Detector 4	116
Photo W/Heat	111
User Defined Detector 5	111

Next >>

Click **Save to Database** to save the configuration to the FS-Tools database.

Click **Save as Template** to use these settings as a template for future panel's settings.

Click **Next** or click **Primary Central Station** in the left pane, to view the **Primary Central Station** configuration pane.

Click **IPOTS-COM Installed** if the IPOTS-COM telephone and IP communicator card is installed on the PCB. The communicator comes pre-installed on some models.

Trouble Call Limit: This field option limits the number of communicator trouble calls to the Central Station, to a programmed amount between 0 and 99, for each unique trouble within a 24 hour period. Separate limit counters keep track of each unique type of trouble. Note that the number of phone line (communication) faults called to the Central Station are not limited by this feature.

Reporting Style: Setting the Report Style to *Point* will program the IPOTS-COM to report individual point status to the Central Station. The control panel is capable of monitoring a total of 50 addressable devices. Setting the Report Style to *Zone* will program the communicator to report zone status to the Central Station. The control panel is capable of monitoring a total of 50 individual zones.

If telephone lines are connected to the IPOTS-COM board at J4 (Line 1) and/or J5 (Line 2), ensure that the **Enabled** checkbox is selected.

The **Supervised Phone Line** feature allows the user to disable the supervision of Phone Lines when using an alternate means of secondary transmission path. The factory default setting is Phone Line supervised.

Type: Select whether each phone line connected to the communicator uses *Touch Tone* format or one of two different types of the *Rotary* format.

Gains Settings

The Gains value is the telephone's transmitting "volume control". The Gains value can be adjusted for when the telephones lines are in use for Dialing and Reporting.

Select Low, Normal, or High from the drop-down boxes.

Test Times

Select the desired **Test Time Interval** (6, 8, 12, or 24 hours) to send the test report to the primary central station.

Enter the **Test Start Time** to program the time at which the communicator will transmit the 24 Hour Test to the Central Station. Enter a four digit number using military time (0000 refers to 12:00AM and 2359 refers to 11:59PM).

Supervision Settings: Choose one of the following from the drop-down menu where the Supervision Interval is the time from the “ping” at AlarmNet to the FACP, and the Fault Time is the duration of the communication loss between the FACP and the cell/ethernet infrastructure (eg. cell tower).

- 2010 IP+CELL: Supervision Interval: 24 Hours, IP Fault Time: 1 Hour, GSM Fault Time: 1 Hour
- 2010 IP: Supervision Interval: 5 min, IP Fault Time: 5 min
- 2013 IP+CELL: Supervision Interval: 6 Hours, IP Fault Time: 1 Hour, GSM Fault Time: 1 Hour
- 2013 IP: Supervision Interval: 1 Hour, IP Fault Time: 1 Hour

If the internet router used by the IPOTS-COM is configured for DHCP (Dynamic Host Configuration Protocol) where addresses are automatically assigned by the router, click the **DHCP Enabled** checkbox. Note that this field is automatically selected when the **IPOTS-COM Installed** checkbox is selected as most routers are configured for DHCP protocol.

Static Settings: These addresses must be set manually if the internet router is not configured for DHCP. Deselect **DHCP Enabled** to activate these fields for editing.

Supervision: Select the desired supervision type from the drop-down box.

Setting:	Supervision Interval:	IP Fault Time:	GSM Fault Time:
2010 IP	5 minutes	5 minutes	N/A
2010 IP + CELL	24 hours	1 hour	1 hour
2013 IP	1 hour	1 hour	N/A
2013 IP + CELL	6 hours	1 hour	1 hour


Central Station Event Codes

Here you can customize the **event codes**. Event codes are the Communicator's way of telling the central station what type of event is taking place. These codes vary based on the selected communication format. When the communication format is selected, the default event code values are shown. They may be changed in this section. Enter zero(es) to disable the reporting of a specific event.

Primary/Secondary Central Station

The FACP reports the fire alarm system status, alarms, and trouble events to the central station. The primary and secondary central station screen are almost identical and allow you to configure the *Communication Path*, *Communication Format*, *Central Station Account Information*, and *Event Codes*.

See the following page to learn more.



The screenshot shows a web-based configuration interface titled "System Info -> Communicator Settings -> Primary Central Station". The main heading is "Primary Central Station". Below this, there are several configuration fields, each with a label, a value field, and a format hint in parentheses:

- Communication Path:** A dropdown menu showing "POTS".
- Phone Number:** A text field containing "FFFFFFFFFFFFFFFFFFFF" with a format hint of "(0-9, A-F)".
- Communication Format:** A dropdown menu showing "ADEMCO CONTACT ID".
- Account Code:** A text field containing "000000" with a format hint of "(0-9)".
- City ID:** A text field containing "0000" with a format hint of "(0-9, A-F)".
- Central Station ID:** A text field containing "0000" with a format hint of "(0-9, A-F)".

At the bottom right of the form, there are two buttons: "<< Prev" and "Next >>". A red rectangular box highlights the entire configuration area, including the labels, value fields, and format hints.

Click **Save to Database** to save the configuration.

Click **Next** or click **Secondary Central Station** in the left pane to configure the secondary central station.

Click **Prev** to go back to the central station settings.

Central Station Settings

Communication Path: Select the communication method for contacting the central station. POTS (Plain Old Telephone Service), Ethernet, or Cellular are available from the drop-down menu.

Note: Use of the CELL-CAB or CELL-MOD GSM Communicator Card is required for Cellular reporting to central station.

When **POTS** is selected:

Enter the **Phone Number** of the primary/secondary central station that the communicator will be contacting. You can enter a maximum of 20 characters with valid entries being 0 to 9 and A - C where A = *, B = # and C = 2 second pause.

Select the **Communication Format** of the reports sent to the primary control station. The primary event codes are displayed based on the communication format used. The Communication Format is determined by the type of receiver that the communicator is transmitting to. Consult your Central Station for proper selection or consult our factory representatives. For any format chosen, the control panel automatically programs all of the event codes. This field is only selectable when POTS is chosen as the communication path.

Type the **Account Code** for the panel assigned by the central station. Each panel has a unique account code depending on the primary central station and the communication format being used.

Type the **City ID** for the panel assigned by the central station.

Type the **Central Station ID** for the panel assigned by the central station.

Input/Output

Relays/Zones

From the **Input/Output** pane, you can configure the FACP's relays, zones, special zones and NACs.

System Info -> Input/Output -> Relays/Zones

Relays

Relay 1: Alarm

Relay 2: Trouble

Relay 3: Supervisory

Zones

Zone Number	Zone Type	Enabled/Disabled	Zone Audio Message
0	Monitor	True	No Zone Message
1	Monitor	True	No Zone Message
2	Monitor	True	No Zone Message
3	Monitor	True	No Zone Message
4	Monitor	True	No Zone Message
5	Monitor	True	No Zone Message
6	Monitor	True	No Zone Message
7	Monitor	True	No Zone Message
8	Monitor	True	No Zone Message
9	Monitor	True	No Zone Message
10	Monitor	True	No Zone Message

Special Zones

☐ Zone 46 - Local Alarm
 ☐ Zone 47 - PAS
 ☐ Zone 48 - Presignal
 ☐ Zone 49 - Two Stage

<< Prev Next >>

Click **Save to Database** to save the configuration.

Click **Next** or click **NAC 1** in the left pane to start configuring the NAC circuits.

Click **Prev** to go back to the secondary central station settings.

Relays

The FACP offers one fixed and two fully programmable Form-C dry contact relays. Relay 1 is factory default programmed as Alarm and programmable Relay 3 is factory default programmed as Supervisory. The relay labeled Relay 2 is fixed as a Trouble relay and cannot be changed. It is a fail-safe relay which will transfer on any trouble or total power failure. Select the desired option for Relays 1 and 3 from the drop-down box.

Possible options are: **Alarm, Supervisory, Supervisory AR, Trouble, Communication Fail, Process Monitoring, Process Monitoring AR, AC Loss, Hazard, Medical, and Silenceable Alarm.**

Notes:

1. AR (AutoResettable) in SUPERVISORY AR and PROCESS MONITORING AR means that a relay with the Supervisory and/or Process Monitor type code, when activated, will automatically reset when the corresponding condition is cleared.
2. A relay programmed with the Silenceable Alarm type will activate upon any alarm and deactivate when the FACP Alarm Silenced LED is illuminated.

Zones

Zone Types: must be programmed only if a Communicator, programmed for zone reporting, is installed on the control panel. From the drop-down box, select the type of zone desired for each installed zone. Zone Types are only relevant for Central Station reporting. Changing a zone type will only change how it is reported to the Central Station. If a tornado zone is required, choose Zone Type "Hazard".

Important! Selecting WATERFLOW will assign a Waterflow silenceable zone type to the selected zone. Any signaling devices programmed to the same zone can be silenced by pressing the Alarm Silence key or by using the auto-silence feature.

Enabled/Disabled: select *Enable* to enable the selected zone. If you select *Disable*, the zone is disabled by the fire panel, preventing the zone circuit from reporting alarms and troubles to the panel. Disabling a zone disables all the functionalities associated with that zone.

Special Zones

Zones 46, 47, 48, and 49 can be programmed for normal zone operation or for special purpose applications.

Zone 46: When Zone 46 is programmed On, a Local Alarm activation of any smoke detector will cause Zone 46 to activate. By assigning Zone 46 to a control module in the Programming Zone Assignment Screen, an output device connected to the control module can be used to indicate a local alarm condition in the control panel. *Local Alarm Zone alarms are not reported to the Central Station.*

Zone 47: When Zone 47 is selected as a special zone, a PAS (Positive Alarm Sequence) activation of any smoke detector will cause Zone 47 to activate. By assigning Zone 47 to a control module in the Zone Mapping section, an output device connected to the control module can be used to indicate a PAS condition in the control panel. *Do not assign Zone 47 to a Notification Appliance Circuit when using this zone to indicate a PAS condition.*

Zone 48: When Zone 48 is selected as a special zone, a Pre-signal activation of any device will cause Zone 48 to activate. By assigning Zone 48 to a control module in the Zone Mapping Section, an output device connected to the control module can be used to indicate a Pre-signal condition in the control panel. *Do not assign Zone 48 to a Notification Appliance Circuit when using this zone to indicate a Pre-signal condition.*

Zone 49: When Zone 49 is selected as a special zone, any time a NAC programmed for two-stage operation moves into the 2nd stage, Z49 will activate. Any control modules assigned to Special Zone 49 will also activate.

NACs

NACs include speakers, horns, strobes, bells, and other type of sounder appliances. There are two notification appliance circuits NAC1 and NAC2, which can be configured for the 50 Point Addressable panel.

Each programming page is identical. See the following page to learn more.

System Info -> Input /Output -> NAC 1

NAC 1 Features

- ☒ NAC 1 Enabled
- ☐ NAC 1 - 1 Minute Silence Inhibit Enabled
- ☒ NAC 1 Silenceable
- NAC 1 Auto Silence:
- NAC 1 Coding:
- NAC 1 Type Code:

Zone Mapping (0-19)

- NAC 1 - 1st Zone:
- NAC 1 - 2nd Zone:
- NAC 1 - 3rd Zone:
- NAC 1 - 4th Zone:
- NAC 1 - 5th Zone:

NAC 1 Synchronization Types – (Only relevant for Sync. Strobe NAC Type)

- ☒ System Sensor
- ☐ Wheelock
- ☐ Gentex

<< Prev Next >>

Click **Save to Database** to save the configuration in the FS-Tools database.

Click **Next** or click **NAC 2** in the left pane to configure NAC 2.

Repeat the process to configure NAC 2.

Click **Next** or click **General System Settings** in the left pane, to view the **General System Settings** configuration pane.

Click **Prev** to go back to the Relays/Zones settings.

NAC Features

To enable each NAC, click the **NAC X Enabled** checkbox. If you do not select the Enable checkbox, the NAC is disabled and the fire panel prevents the selected NAC from activating its devices.

Click **Minute Silence Inhibit Enabled** to enable the silencing of the audible devices in NAC X, only after 60 seconds. If this option is enabled, the audible devices can be silenced by pressing the Alarm Silence key, only after 60 seconds.

Click **Silenceable** to indicate whether the NAC can be silenced by pressing the Alarm Silence key. If the Silenceable option is not enabled, the selected NACs cannot be silenced by pressing the Alarm Silence key or by the Auto Silence feature.

Select the delay time for **Auto Silence** from the list to automatically silence the main circuit board silenceable NACs after a programmed length of time. This option is disabled if the option is not selected.

Select the **Coding** option to specify the type of output the main circuit board notification appliances generates when activated. Click here for more information about each coding selection.

Select the NAC device type from the list in the **Type Code** drop-down box. Type code options are: Bell, Horn, Strobe, Synced Strobe (Synchronized to manufacturer), Strobe Sil Sync (same as Synced Strobe but Silence turns off audible & visual devices), or Blank.

NAC Synchronization Types

Select the **Synchronization Type** which can be *System Sensor*, *Wheelock*, or *Gentex*. Synchronization is a panel feature that controls the activation of notification appliances in such a way that devices turn on and off at exactly the same time. For more information about synchronization, see Synchronized NAC Operation.

NAC Synchronization Type can be selected only for the *Sync Strobe* or *Strobe Sil Sync* **NAC Type Code**.

NAC Zone Mapping

Under **Zone Mapping**, enter the three digit number corresponding to the zone assigned to NAC X. A maximum of five zones can be configured for each main circuit board NAC. The factory default for an unprogrammed device is Z000 for general/local alarm zone.

General System Settings

In this screen, you can configure the FACP's general system settings. See the following pages to learn more.

System Info -> General System Settings

Timers

Positive Alarm Sequence Delay: 0 (0-180) seconds

Alarm Presignal Delay: 0 (0-180) seconds

Waterflow Retard: 0 (0-90) seconds

AC Loss Delay: 2 (0-23) hours

Control Module Delay Timer: 0 (0-180) seconds

Clock Format

☒ 12-Hour Format ☐ 24-Hour Format

Loop Style

Loop 1 Style: Style 4

Protocol Type

Loop Protocol: LITE SPEED

Language Support

Language: English

Trouble Reminder: 24 HR ☐ 4XTM Supervision Enable

☐ Waterflow Devices Silenceable ☒ Battery Charger Enable

☐ Canadian Option Enabled ☒ Remote Sync Enable

☐ MNS Override

☒ Enable Daylight Savings Time

Daylight Savings

Daylight Savings Time Starts: Week 2 of March

Daylight Savings Time Ends: Week 1 of November

Auxiliary Power Settings

Aux 1 ☐ Class A ☐ Resettable

Banner Display

☐ User ☒ Factory

User Programmable Banner

Banner 1: Banner 2:

<< Prev Next >>

Click **Save to Database** to save the configuration in the FS-Tools database.

Click **Next** or click **Global Options** in the left pane to configure the global ANN-BUS settings.

Click **Prev** to go back to the **NAC** settings.

Timers

The **Timers** option allows you to set the times for a:

PAS (Positive Alarm Sequence) delay can be programmed for a delay of 0-180 seconds. This option is unavailable if the [Canadian Option](#) is selected.

Pre-Signal delay can be programmed for a delay of 0-180 seconds. This option is unavailable if the [Canadian Option](#) is selected.

Waterflow Retard delay can be programmed for a delay of 0-90 seconds.

AC Loss delay can be programmed for a delay of 0-23 hours. The factory default setting is 2 hours.

Control Module Delay can be programmed for a delay of 0-180 seconds.

The **Trouble Reminder** feature provides an audible reminder that an alarm or trouble still exists on the FACP after the control panel has been silenced. The control panel piezo sounder will pulse once every 15 seconds during an alarm and every two minutes during a trouble condition, after the Alarm Silence or Acknowledge key is pressed. The piezo will continue to sound at these rates until the alarm or trouble condition is cleared. If the trouble condition is not cleared within the selected 4 or 24 hours, the panel will reactivate the trouble sounder and retransmit the trouble condition to the central station if connected.

The **Waterflow Devices Silenceable** option provides the ability to silence any output circuit activated by a monitor module programmed as a waterflow type.

The **Canadian Option** feature, when enabled, configures the FACP with the following as required by Canada:

- The following monitor module type codes are not available: monitor, non-latching supervisory, non-latching drill, non-latching process monitor, hazard, tornado, medical alert
- Addressable ionization smoke detector sensitivity is automatically monitored using Canadian specifications.
- The Positive Alarm Sequence, the Pre-Signal option, the Auto-Silence option, and the Silence Inhibit Timer are not available for Canadian applications.
- The Auto-silence timer is fixed at 20 minutes and cannot be changed.
- The F1 function key is automatically configured to perform a manual alarm signal activation when pressed.
- The F2 function key is automatically configured to perform a two-stage bypass when pressed.

For Canadian applications, remote annunciation must be done using the secondary ANN-BUS.

The **4XTM Supervision Enable** checkbox *must* be selected if a 4XTM(F) module is installed on the FACP.

The **Battery Charger Enable** option allows you to disable the onboard battery charger in the event an external battery charger is being used.

The **Remote Sync Enable** option allows you to sync NAC devices connected to an external power supply. The devices will sync with NAC1 on the FACP. Remote Sync requires wiring from the Remote Sync output terminal block to the Remote sync input on the FCPS power supply.

Daylight Savings Time

If selected, the control panel will automatically update the time for **daylight savings time**.

Use the drop-down boxes to select the week and month for daylight savings **start** and **end** times.

Clock Format

The **Clock Format** feature allows you to set the time display format (24 hour or 12 hour) in the FACP memory.

Loop Style

Loop Style option allows you to select the loop style for the panel's SLC (Signaling Line Circuit). The panel may be wired in Class B (Style 4), a two-wire circuit starting at the panel and ending at the last device, or Class A (Styles 6 or 7), a four-wire circuit starting at the panel going out to all the devices, and ending back at the panel. Style 7 wiring uses isolator modules, one on each side of the loop.

Protocol Type

Protocol Type: The FACP operates in two SLC polling styles, **LiteSpeed** or **CLIP** (Classic Loop Interface Protocol). LiteSpeed is a communication protocol that greatly enhances the speed of communication between analog intelligent devices. This is the default mode of operation for this FACP. CLIP mode polls devices in sequential order. All addressable FACP can operate in CLIP mode.

Note that the legacy devices can operate only in CLIP mode while the newer devices are compatible with CLIP and LiteSpeed modes of operation. If any legacy, CLIP mode device is installed on the system, the Protocol type must then be set to CLIP.

Language Support

Language Support: The FACP is capable of displaying panel display text in either **English** or **French**. Select the desired language from the drop-down menu.

Aux Settings

The FACP provides one 24VDC outputs for powering auxiliary devices.

If these devices are wired in **Class A** configuration, the Class A checkbox must be selected.

The Aux power is configured for **Non-Resettable** power (suitable for powering annunciators). If **Resettable** Power is desired instead (suitable for powering smoke detectors), ensure that the **Resettable** checkbox is selected.

Banner Display

The **Banner Display** option allows you to choose from either a factory default or custom banner for the top two lines of the LCD display on the fire panel. You can change the factory default to a custom defined readout when the fire panel is in normal condition. A maximum of 20 characters, including spaces, can be entered for each line on the display.

ANN-Bus Settings

Global Options

The ANN-Bus is a communication circuit on the fire panel over which different ANN devices can be installed to communicate with the FACP. You can configure the ANN-Bus when any ANN devices are installed. See following pages to learn more.

Refer to the [ANN-BUS Guidelines](#) for more information when using both the primary ANN-BUS and the secondary ANN-BUS.

System Info -> ANN Bus Settings -> Global Options

Primary ANN Bus

ANN Bus Enable ☒ Yes ☐ No

CLASS A ☒

Secondary ANN Bus

ANN Bus Enable ☒ Yes ☐ No

Global Settings

ANN S/PG Options

Port: Serial

Printer Supervision: True

Baud Rate: 9600

Parity: Even

Data Bits: 7

Offline Timer: 60

Stop Bits: 1

ANN LED Options

Piezo Enable ☒ Yes ☐ No

Lamp Test Enable ☒ Yes ☐ No

Silence Button Enable ☒ Yes ☐ No

ANN 80 Options

Lock Enable ☒ Yes ☐ No

Ack/Step (Also Applicable for Canadian Option) Enable ☒ Yes ☐ No

Silence Enable ☒ Yes ☐ No

Piezo Enable ☒ Yes ☐ No

Reset/Lamp (Applicable for Canadian Option only) Enable ☒ Yes ☐ No

Drill/Sounder (Applicable for Canadian Option only) Enable ☒ Yes ☐ No

Click **Save to Database** to save the configuration in the FS-Tools database.

Click **Next** or click **Primary ANN Bus** in the left pane configure the **Primary ANN-Bus Settings**.

Click **Prev** to go back to the **General System Settings** pane.

ANN-BUS Guidelines

- A variety of optional annunciation devices can be connected to an ANN-BUS communication circuit. ANN Series devices can be connected to the primary communication circuit (EIA-485) terminals on TB9. A secondary communication circuit for these devices is available at TB10. Each ANN-BUS communication circuit supports up to eight (8) annunciators.
- When operating two ANN-BUS circuits, only one ANN-S/PG Printer module can be used in the system.
- The panel is capable of operating a primary ANN-BUS (TB9) and a secondary ANN-BUS (TB8) simultaneously.

Primary/Secondary ANN Bus

Click **Yes** to enable the Primary and/or Secondary ANN-Bus. You must enable the ANN-Bus if any modules are connected to the Primary ANN-Bus terminal at TB9 or to the Secondary ANN-Bus terminal at TB10 on the main circuit board.

The primary ANN-Bus is capable of operating in **Class A** configuration. Select the checkbox if the primary Ann-Bus is wired for Class A operation.

The following are the compatible devices that may be available for connection to the ANN-Bus communication circuit.

- ANN-80 LCD Annunciator
- ANN-100 (for FM and Canadian applications)
- ANN-S/PG Serial/Parallel Printer Interface Module
- ANN-I/O LED Driver Module
- ANN-(R)LED LED Annunciator Module (alarm, trouble, supervisory LEDs)
- ANN-RLY Relay Module

ANN-S/PG Options

The ANN-S/PG options allows you to connect a remote serial or parallel printer to the FACP. This helps you to log system events, detector status reports and event history. If Parallel port is selected, you can supervise and set the offline timer for the printer. If Serial port is selected, you can set the Baud Rate, Parity, Data Bits, and Stop Bits.

Under **ANN S/PG options**, select the type of **Port** for the printer connection, either Serial or Parallel.

- If you select **Parallel** port, the following fields are activated:
- In the **Printer Supervision** list, select *to enable* or *false* to disable printer supervision.
- In the **Offline Timer** box, enter offline for delay, between 0 and 255 seconds, before loss of printer supervision is reported as a trouble.
- If you select **Serial** port, the following fields are activated:
- In **Baud Rate** list, select a baud rate in the range *2400*, *9600*, or *19200*.
- In **Parity** list, select *Even*, *Odd*, or *None*.
- In **Data Bits** list, select 7 or 8 bits.
- In **Stop Bits** list, select *0.5*, *1*, or *2*.

ANN-LED Options

The **Piezo Enable** option allows you to select whether the piezo sounder on any installed ANN-LED module will ever sound. Select *yes* to enable or *no* to disable.

The **Lamp Test Enable** option allows you to select whether the Lamp Test button on any installed ANN-LED annunciator will function normally or always be ignored. Select *yes* to enable or *no* to disable.

The **Silence Button Enable** option allows you to select whether the Silence button on any installed ANN-LED annunciator will function normally or always be ignored. Select *yes* to enable or *no* to disable.

ANN-80 Options

The **Lock Enable** option allows you to select whether or not any installed ANN-80 annunciator must be unlocked by its key before any annunciator key presses will function. Select *yes* to enable (annunciator must be unlocked for keys to function) or *no* to disable (lock position is ignored).

The **Acknowledge/Step Enable** option allows you to select whether the Ack/Step button on any installed ANN-80 annunciator will function normally or always be ignored. Select *yes* to enable (Ack/Step button functions normally) or *no* to disable (Ack/Step button never functions).

The **Silence Enable** option allows you to select whether the Silence button on any installed ANN-80 annunciator will function normally or always be ignored. Select *yes* to enable (Silence button functions normally) or *no* to disable (Silence button never functions).


The **Piezo Enable** option allows you to select whether the piezo sounder on any installed ANN-80 module will ever sound. Select *yes* to enable or *no* to disable.

The **Reset/Lamp Enable** option allows you to select whether the Reset button on any installed ANN-80 annunciator will function normally or always be ignored. Select *yes* to enable (Reset button functions normally) or *no* to disable (Reset button never functions).

The **Drill/Sounder Enable** option allows you to select whether the Drill button on any installed ANN-80 annunciator will function normally or always be ignored. Select *yes* to enable (Drill button functions normally) or *no* to disable (Drill button never functions).

Primary/Secondary ANN-Bus

For each enabled ANN-Bus address, select the module type from the drop-down box. The Primary and Secondary ANN-Bus screens are identical.




Address	Module Type	Status
1	Not Installed	N/A
2	Not Installed	N/A
3	Not Installed	N/A
4	Not Installed	N/A
5	Not Installed	N/A
6	Not Installed	N/A
7	Not Installed	N/A
8	Not Installed	N/A

Available ANN-Bus modules may include the:

- ANN-80 LCD Annunciator
- ANN-100 LCD Annunciator
- ANN-I/O LED Driver Module
- ANN-S/PG Serial/Parallel Printer Interface Module
- ANN-LED Annunciator Module
- ANN-RLED Annunciator Module
- ANN-RLY Relay Module

The ANN-I/O, ANN-(R)LED, and ANN-RLY require input in the status field. After selecting one of these devices from the drop-down menu, double-click in the "Status" field to finish device setup.

ANN-I/O



Select whether the ANN-I/O will annunciate either Point (addressable device address) information or Zone information and select the [Point Range](#) to be annunciated. The only [zone range](#) that can be annunciated on the 50 Pt. Addressable panel is Zone 0-13.

ANN-I/O Point Option

If Point is selected as the module option, the first ten LED driver outputs on the first ANN-I/O module will display the system status information. The remaining 30 LED driver outputs on the first module and 20 LED driver outputs on the second module will be used to display the active/alarm status of each point in the Point Range programmed for that particular module. The points that will be annunciated on a particular ANN-I/O module depend on the programming options selected as far as the device type (detector or module) to be annunciated. The LED assignments for each ANN-I/O module will be as follows.

Module LED	ANN-I/O Module #1 Function	ANN-I/O Module #2 Function
1	AC Fault	Not Used
2	Fire Alarm	Not Used
3	Supervisory	Not Used
4	Trouble	Not Used
5	Alarm Silenced	Not Used
6	Not Used	Not Used
7	Not Used	Not Used
8	Not Used	Not Used
9	Not Used	Not Used
10	Not Used	Not Used
11	Point 001 - Active/Alarm	Point 031 - Active/Alarm

12	Point 002 - Active/Alarm	Point 032 - Active/Alarm
13	Point 003 - Active/Alarm	Point 033 - Active/Alarm
14	Point 004 - Active/Alarm	Point 034 - Active/Alarm
15	Point 005 - Active/Alarm	Point 035 - Active/Alarm
16	Point 006 - Active/Alarm	Point 036 - Active/Alarm
17	Point 007 - Active/Alarm	Point 037 - Active/Alarm
18	Point 008 - Active/Alarm	Point 038 - Active/Alarm
19	Point 009 - Active/Alarm	Point 039 - Active/Alarm
20	Point 010 - Active/Alarm	Point 040 - Active/Alarm
21	Point 011 - Active/Alarm	Point 041 - Active/Alarm
22	Point 012 - Active/Alarm	Point 042 - Active/Alarm
23	Point 013 - Active/Alarm	Point 043 - Active/Alarm
24	Point 014 - Active/Alarm	Point 044 - Active/Alarm
25	Point 015 - Active/Alarm	Point 045 - Active/Alarm
26	Point 016 - Active/Alarm	Point 046 - Active/Alarm
27	Point 017 - Active/Alarm	Point 047 - Active/Alarm
28	Point 018 - Active/Alarm	Point 048 - Active/Alarm
29	Point 019 - Active/Alarm	Point 049 - Active/Alarm
30	Point 020 - Active/Alarm	Point 050 - Active/Alarm
31	Point 021 - Active/Alarm	Not Used
32	Point 022 - Active/Alarm	Not Used
33	Point 023 - Active/Alarm	Not Used
34	Point 024 - Active/Alarm	Not Used
35	Point 025 - Active/Alarm	Not Used
36	Point 026 - Active/Alarm	Not Used
37	Point 027 - Active/Alarm	Not Used
38	Point 028 - Active/Alarm	Not Used
39	Point 029 - Active/Alarm	Not Used
40	Point 030 - Active/Alarm	Not Used


ANN-I/O Zone Option

If Zone is selected as the module option, the first ten LED driver outputs on the ANN-I/O module will display the system status information. The remaining 20 LED driver outputs on the module will display the active/alarm status of each zone. The LED assignments for the ANN-I/O module will be as follows.

Module LED	Zone Range 000-029 Function	Zone Range 030-049 Function
1	AC Fault	Zone 030 - Active/Alarm
2	Fire Alarm	Zone 031 - Active/Alarm
3	Supervisory	Zone 032 - Active/Alarm
4	Trouble	Zone 033 - Active/Alarm
5	Alarm Silenced	Zone 034 - Active/Alarm
6	Earth Fault	Zone 035 - Active/Alarm
7	Battery Fault	Zone 036 - Active/Alarm
8	Charger Fault	Zone 037 - Active/Alarm
9	NAC Fault	Zone 038 - Active/Alarm
10	Disabled	Zone 039 - Active/Alarm
11	Zone 000 - Active/Alarm	Zone 040 - Active/Alarm
12	Zone 001 - Active/Alarm	Zone 041 - Active/Alarm
13	Zone 002 - Active/Alarm	Zone 042 - Active/Alarm
14	Zone 003 - Active/Alarm	Zone 043 - Active/Alarm
15	Zone 004 - Active/Alarm	Zone 044 - Active/Alarm
16	Zone 005 - Active/Alarm	Zone 045 - Active/Alarm
17	Zone 006 - Active/Alarm	Zone 046 - Active/Alarm
18	Zone 007 - Active/Alarm	Zone 047 - Active/Alarm
19	Zone 008 - Active/Alarm	Zone 048 - Active/Alarm
20	Zone 009 - Active/Alarm	Zone 049 - Active/Alarm
21	Zone 010 - Active/Alarm	Not Used
22	Zone 011 - Active/Alarm	Not Used
23	Zone 012 - Active/Alarm	Not Used
24	Zone 013 - Active/Alarm	Not Used
25	Zone 014 - Active/Alarm	Not Used
26	Zone 015 - Active/Alarm	Not Used
27	Zone 016 - Active/Alarm	Not Used
28	Zone 017 - Active/Alarm	Not Used
29	Zone 018 - Active/Alarm	Not Used
30	Zone 019 - Active/Alarm	Not Used
31	Zone 020 - Active/Alarm	Not Used
32	Zone 021 - Active/Alarm	Not Used

33	Zone 022 - Active/Alarm	Not Used
34	Zone 023 - Active/Alarm	Not Used
35	Zone 024 - Active/Alarm	Not Used
36	Zone 025 - Active/Alarm	Not Used
37	Zone 026 - Active/Alarm	Not Used
38	Zone 027 - Active/Alarm	Not Used
39	Zone 028 - Active/Alarm	Not Used
40	Zone 029 - Active/Alarm	Not Used

ANN-(R)LED



Select whether the ANN-LED will annunciate either [Point information](#) (addressable device address) or [Zone information](#) and select whether the ANN-LED will annunciate alarms only or alarms, troubles, and supervisories.

ANN-LED Point Option

Alarm Only (for use with ANN-RLED module)

If Point is selected as the module option and the module is programmed to annunciate alarms only, the first ten LEDs on the first ANN-RLED module will display the system status information. The remaining 30 LEDs on the first module and LEDs 11 - 30 on the second module will display the active/alarm status of each point in the Point Range programmed for that particular module. The LED assignments for each ANN-RLED module will be as follows.

Alarm Silenced	NAC 1 Fault	NAC 2 Fault	Not Used	Not Used
Earth Fault	Battery Fault	Charger Fault	Disabled	Maintenance
Point 001 Active/Alarm	Point 002 Active/Alarm	Point 003 Active/Alarm	Point 004 Active/Alarm	Point 005 Active/Alarm
Point 006 Active/Alarm	Point 007 Active/Alarm	Point 008 Active/Alarm	Point 009 Active/Alarm	Point 010 Active/Alarm
Point 011 Active/Alarm	Point 012 Active/Alarm	Point 013 Active/Alarm	Point 014 Active/Alarm	Point 015 Active/Alarm
Point 016 Active/Alarm	Point 017 Active/Alarm	Point 018 Active/Alarm	Point 019 Active Alarm	Point 020 Active/Alarm
Point 021 Active/Alarm	Point 022 Active/Alarm	Point 023 Active/Alarm	Point 024 Active/Alarm	Point 025 Active/Alarm
Point 026 Active/Alarm	Point 027 Active/Alarm	Point 028 Active/Alarm	Point 029 Active/Alarm	Point 030 Active/Alarm

ANN-RLED Module #1 (Point Range 001-030)

Not Used	Not Used	Not Used	Not Used	Not Used
Not Used	Not Used	Not Used	Not Used	Not Used
Point 031 Active/Alarm	Point 032 Active/Alarm	Point 033 Active/Alarm	Point 034 Active/Alarm	Point 035 Active/Alarm
Point 036 Active/Alarm	Point 037 Active/Alarm	Point 038 Active/Alarm	Point 039 Active/Alarm	Point 040 Active/Alarm
Point 041 Active/Alarm	Point 042 Active/Alarm	Point 043 Active/Alarm	Point 044 Active/Alarm	Point 045 Active/Alarm
Point 046 Active/Alarm	Point 047 Active/Alarm	Point 048 Active/Alarm	Point 049 Active Alarm	Point 050 Active/Alarm
Not Used	Not Used	Not Used	Not Used	Not Used
Not Used	Not Used	Not Used	Not Used	Not Used

ANN-RLED Module #2 (Point Range 031-050)

Alarm, Trouble and Supervisory

If Point is selected as the module option, and the module is programmed to annunciate alarms, troubles and supervisories, the first ten LEDs on the first ANN-LED module will display the system status information. The remaining 30 LEDs on the first module and the last 30 LEDs on the remaining modules will display the alarm, trouble and supervisory status for each of the ten points in the Point Range programmed for that particular module. The LED assignments for each ANN-LED module will be as follows.

Alarm Silenced	NAC 1 Fault	NAC 2 Fault	Not Used	Not Used
Earth Fault	Battery Fault	Charger Fault	Disable	Maintenance
Point 001 Active/Alarm	Point 002 Active/Alarm	Point 003 Active/Alarm	Point 004 Active/Alarm	Point 005 Active/Alarm
Point 001 Trouble	Point 002 Trouble	Point 003 Trouble	Point 004 Trouble	Point 005 Trouble
Point 001 Supervisory	Point 002 Supervisory	Point 003 Supervisory	Point 004 Supervisory	Point 005 Supervisory
Point 006 Active/Alarm	Point 007 Active/Alarm	Point 008 Active/Alarm	Point 009 Active Alarm	Point 010 Active/Alarm
Point 006 Trouble	Point 007 Trouble	Point 008 Trouble	Point 009 Trouble	Point 010 Trouble
Point 006 Supervisory	Point 007 Supervisory	Point 008 Supervisory	Point 009 Supervisory	Point 010 Supervisory

ANN-LED Module #1 (Point Range 001-010)

Not Used	Not Used	Not Used	Not Used	Not Used
Not Used	Not Used	Not Used	Not Used	Not Used
Point 011 Active/Alarm	Point 012 Active/Alarm	Point 013 Active/Alarm	Point 014 Active/Alarm	Point 015 Active/Alarm
Point 011 Trouble	Point 012 Trouble	Point 013 Trouble	Point 014 Trouble	Point 015 Trouble
Point 011 Supervisory	Point 012 Supervisory	Point 013 Supervisory	Point 014 Supervisory	Point 015 Supervisory
Point 016 Active/Alarm	Point 017 Active/Alarm	Point 018 Active/Alarm	Point 019 Active Alarm	Point 020 Active/Alarm
Point 016 Trouble	Point 017 Trouble	Point 018 Trouble	Point 019 Trouble	Point 020 Trouble
Point 016 Supervisory	Point 017 Supervisory	Point 018 Supervisory	Point 019 Supervisory	Point 020 Supervisory

ANN-LED Module #2 (Point Range 011-020)

The LED assignments for the modules annunciating Point Ranges 021-030, 031-040 and 041-050, will follow the same pattern as the second ANN-LED Module: third module Point Range 021-030, fourth module Point Range 031-040 and fifth module Point Range 041-050.

ANN-LED Zone Options

Alarm Only (for use with ANN-RLED module)

If Zone is selected as the module option, and the module is programmed to annunciate alarms only, the first ten LEDs on the ANN-RLED module will display the system status information. The remaining 30 LEDs on the first module and the last 30 LEDs on the second module will display the active/alarm status of each zone in the Zone Range programmed for that particular module. The LED assignments for each ANN-LED module will be as follows.

Alarm Silenced	NAC 1 Fault	NAC 2 Fault	Not Used	Not Used
Earth Fault	Battery Fault	Charger Fault	Disabled	Maintenance
Zone 000 Active/Alarm	Zone 001 Active/Alarm	Zone 002 Active/Alarm	Zone 003 Active/Alarm	Zone 004 Active/Alarm
Zone 005 Active/Alarm	Zone 006 Active/Alarm	Zone 007 Active/Alarm	Zone 008 Active/Alarm	Zone 009 Active/Alarm
Zone 010 Active/Alarm	Zone 011 Active/Alarm	Zone 012 Active/Alarm	Zone 013 Active/Alarm	Zone 014 Active/Alarm
Zone 015 Active/Alarm	Zone 016 Active/Alarm	Zone 017 Active/Alarm	Zone 018 Active Alarm	Zone 019 Active/Alarm
Zone 020 Active/Alarm	Zone 021 Active/Alarm	Zone 022 Active/Alarm	Zone 023 Active/Alarm	Zone 024 Active/Alarm
Zone 025 Active/Alarm	Zone 026 Active/Alarm	Zone 027 Active/Alarm	Zone 028 Active/Alarm	Zone 029 Active/Alarm

ANN-RLED Module #1

Not Used	Not Used	Not Used	Not Used	Not Used
Not Used	Not Used	Not Used	Not Used	Not Used
Zone 030 Active/Alarm	Zone 031 Active/Alarm	Zone 032 Active/Alarm	Zone 033 Active/Alarm	Zone 034 Active/Alarm
Zone 035 Active/Alarm	Zone 036 Active/Alarm	Zone 037 Active/Alarm	Zone 038 Active/Alarm	Zone 039 Active/Alarm
Zone 040 Active/Alarm	Zone 041 Active/Alarm	Zone 042 Active/Alarm	Zone 043 Active/Alarm	Zone 044 Active/Alarm
Zone 045 Active/Alarm	Zone 046 Active/Alarm	Zone 047 Active/Alarm	Zone 048 Active Alarm	Zone 049 Active/Alarm
Not Used	Not Used	Not Used	Not Used	Not Used
Not Used	Not Used	Not Used	Not Used	Not Used

ANN-RLED Module #2

ANN-LED Zone Option - Alarm, Trouble and Supervisory

If Zone is selected as the module option, and the module is programmed to annunciate alarms, troubles, and supervisories, the first ten LEDs on the first ANN-LED module will display the system status information. The remaining 30 LEDs on the first module and the last 30 LEDs on the second module will display the alarm, trouble and supervisory status for each of the ten zones in the Zone Range programmed for that particular module. The LED assignments for each ANN-LED module will be as follows.

Alarm Silenced	NAC 1 Fault	NAC 2 Fault	Not Used	Not Used
Earth Fault	Battery Fault	Charger Fault	Disabled	Maintenance
Zone 000 Active/Alarm	Zone 001 Active/Alarm	Zone 002 Active/Alarm	Zone 003 Active/Alarm	Zone 004 Active/Alarm
Zone 000 Trouble	Zone 001 Trouble	Zone 002 Trouble	Zone 003 Trouble	Zone 004 Trouble
Zone 000 Supervisory	Zone 001 Supervisory	Zone 002 Supervisory	Zone 003 Supervisory	Zone 004 Supervisory
Zone 005 Active/Alarm	Zone 006 Active/Alarm	Zone 007 Active/Alarm	Zone 008 Active Alarm	Zone 009 Active/Alarm
Zone 005 Trouble	Zone 006 Trouble	Zone 007 Trouble	Zone 008 Trouble	Zone 009 Trouble
Zone 005 Supervisory	Zone 006 Supervisory	Zone 007 Supervisory	Zone 008 Supervisory	Zone 009 Supervisory

ANN-LED Module #1

Not Used	Not Used	Not Used	Not Used	Not Used
Not Used	Not Used	Not Used	Not Used	Not Used
Zone 010 Active/Alarm	Zone 011 Active/Alarm	Zone 012 Active/Alarm	Zone 013 Active/Alarm	Zone 014 Active/Alarm
Zone 010 Trouble	Zone 011 Trouble	Zone 012 Trouble	Zone 013 Trouble	Zone 014 Trouble
Zone 010 Supervisory	Zone 011 Supervisory	Zone 012 Supervisory	Zone 013 Supervisory	Zone 014 Supervisory
Zone 015 Active/Alarm	Zone 016 Active/Alarm	Zone 017 Active/Alarm	Zone 018 Active Alarm	Zone 019 Active/Alarm
Zone 015 Trouble	Zone 016 Trouble	Zone 017 Trouble	Zone 018 Trouble	Zone 019 Trouble
Zone 015 Supervisory	Zone 016 Supervisory	Zone 017 Supervisory	Zone 018 Supervisory	Zone 019 Supervisory

ANN-LED Module #2

The LED assignments for the modules annunciating Zone Ranges 020-029, 030-039, and 040-049 will follow the same pattern as the second ANN-LED module.

ANN-RLY

Relay	Relay
Relay 1	Zone Active 0
Relay 2	Zone Active 0
Relay 3	Zone Active 0
Relay 4	Zone Active 0
Relay 5	Zone Active 0
Relay 6	Zone Active 0
Relay 7	Zone Active 0
Relay 8	Zone Active 0
Relay 9	Zone Active 0
Relay 10	Zone Active 0

Buttons: Save And Exit, Cancel

The ANN-RLY module provides ten Form-C relays which can be programmed for various functions. Select the desired relay function from the drop-down menu. Following is a list of the available programming options for each relay:

- Alarm
- Supervisory
- Supervisory AR
- Trouble
- Comm Fail
- Process Mon
- Process Mon AR
- AC Loss
- Hazard
- Medical
- Silenceable Alarm
- Carbon Monoxide
- Zone Active XXX (where XXX = programmed zone 000 to 049)

Click **Save to Database** to save the configuration in the FS-Tools database.

Click **Next** or click **Function Keys** in the left pane configure the four programmable keypad Function Keys.

Click **Prev** to go back to the **Global Options** pane.

Function Keys

The FACP keypad has 4 programmable function keys. These keys can be programmed to allow rapid disable/enable of various fire panel inputs and outputs during scheduled maintenance.

The screenshot shows the 'System Info -> Function Keys' configuration window. It contains four rows, each representing a function key. Each row has a checkbox labeled 'Function Key 1' through 'Function Key 4', all of which are checked. To the right of each checkbox is a dropdown menu with four options: 'Zones', 'All Zones', 'NAC', and 'Remote Sync'. For each key, there are two buttons: 'View/edit Zones for F1' (highlighted with a red box) and 'View/edit NAC for F1' (highlighted with a red box). At the bottom right, there are two buttons: '<< Prev' and 'Next >>'.


Click **Save to Database** to save the configuration in the FS-Tools database.

Click **Next** or click **SLC Loop Setup>Detectors** in the left pane to configure Input devices.

Click **Prev** to go back to the **Secondary ANN-Bus setup**.


Function Key Zone Select

Select which **Zones** (0-19) that the Function Key will control.



Function Key NAC Select

Select which **NAC** (1 or 2) that the Function Key will control.



SLC Loop Set-up

SLC Loop

SLC loops provide communication to addressable detectors, monitor modules (initiating devices, and control modules (output devices. One SLC loop is available for use on the FACP. The device capacity is 50 devices total.

You can configure the SLC Loop for NFPA Class B (Style 4) or Class A (Styles 6 or 7. [Wiring styles](#) 4 or 6 are most common. Style 7 wiring is the same as Style 6 with the added requirement that each addressable device on the loop must have a pair of isolator modules, one on each side. To program a system for Style 7, you must select the loop setup for Style 6. Refer to your *SLC Wiring Manual* for more information.

Loop Style

Loop Style option allows you to select the loop style for the panel's SLC (Signaling Line Circuit). The panel may be wired in Class B (Style 4), a two-wire circuit starting at the panel and ending at the last device, or Class A (Styles 6 or 7), a four-wire circuit starting at the panel going out to all the devices, and ending back at the panel. Style 7 wiring uses isolator modules, one on each side of the loop.

Detectors

From the detectors screen, you can:

- [Add](#) a new addressable detector to the SLC loop.
- View the added detector in a [tabular](#) or [graphical](#) form
- [Edit](#) the programming for an existing detector.
- [Delete](#) an existing detector from the loop.
- [Search](#) for detectors in a zone.

Adding Devices

From the bottom of the detector screen, select the Add Device(s) button. The following screen appears. See following pages to learn more.

The screenshot shows the 'Add' dialog box for SLC Setup -> Device Settings -> Detectors. The dialog is divided into several sections, each highlighted with a red border:

- Device Address:** Includes radio buttons for 'Loop1' (selected) and 'Multiple Devices'. The 'Address' field is empty. The 'No. of devices' is set to 1.
- Device Type:** A dropdown menu showing 'SMOKE(PHOTO)' and an 'Edit Custom Type' button.
- Device Label:** Includes dropdown menus for 'Adjective' and 'Noun', a 'Delete Custom Adjective/Noun' button, and a 'Custom Label' field.
- Device Options:** A list of checkboxes: 'Device Enabled' (checked), 'Pre-Signal Enabled' (unchecked), 'PAS Enabled' (unchecked), 'Device Walktestable' (checked), 'Alarm Verification Enabled' (unchecked), and 'Device Silenceable' (unchecked).
- Zone (0-19):** A list of five zones with input fields: 'Zone 1' (0), 'Zone 2' (empty), 'Zone 3' (empty), 'Zone 4' (empty), and 'Zone 5' (empty).
- Sounder Base Detector Options:** Includes checkboxes for 'Sounder Base Installed' (unchecked) and 'Device Silenceable' (checked), a 'Volume' dropdown, a 'Coding' dropdown, and a 'SounderBase Zones' button.
- Wireless Option:** A checkbox for 'Wireless' (unchecked).

At the bottom of the dialog are 'OK' and 'Cancel' buttons.














Click OK when finished and the device(s) will appear on the detector screen.

Viewing Devices

There are two ways the devices can be viewed. There is a **tabular view** which outlines the device information in a table view.

Loop	Address	Status	Type	Verification	Walktest	Presignal	PAS	Custom Label	SounderBase Installed	Coding
1	1	Enable	PHOTO BEAM	False	True	False	False	EAST FLOOR	False	
1	2	Enable	SMOKE (ION)	False	True	False	False	SOUTH CLASSR...	False	
1	3	Enable	SMOKE(PHOTO)	False	True	True	False	MAIN CORRIDOR	False	
1	4	Enable	PHOTO ADAPT	False	True	True	False	UPPER HALLWAY	False	STEADY
1	5	Enable	PHOTO ADAPT	False	True	True	False	UPPER HALLWAY	False	
1	6	Enable	PHOTO ADAPT	False	True	True	False	UPPER HALLWAY	False	
1	7	Enable	PHOTO ADAPT	False	True	True	False	UPPER HALLWAY	False	
1	8	Enable	PHOTO ADAPT	False	True	True	False	UPPER HALLWAY	False	
1	9	Enable	PHOTO ADAPT	False	True	True	False	UPPER HALLWAY	False	
1	10	Enable	PHOTO ADAPT	False	True	True	False	UPPER HALLWAY	True	
1	11	Enable	PHOTO ADAPT	False	True	True	False	UPPER HALLWAY	True	STEADY
1	12	Enable	PHOTO ADAPT	False	True	True	False	UPPER HALLWAY	True	
1	13	Enable	PHOTO ADAPT	False	True	True	False	UPPER HALLWAY	True	
1	14	Enable	PHOTO ADAPT	False	True	True	False	UPPER HALLWAY	False	
1	15	Enable	PHOTO ADAPT	False	True	True	False	UPPER HALLWAY	False	
1	16	Enable	PHOTO ADAPT	False	True	True	False	UPPER HALLWAY	False	

The graphical view offers a pictorial view of the devices on the loop.

	1	2	3	4	5	6	7	8	9	10
1-10										
11-20										
21-30										
31-40										
41-50										

Editing Devices

Using the **Edit Devices** option, you can edit the device type, device options, and change the zone mapping.

Select the check box corresponding to the device you want to edit in the **Detectors** screen. You can select only one device at a time.

Click **Edit Device(s)** to edit the device information. The **Edit** dialog box appears.

Edit

SLC Setup -> Device Settings -> Detectors

Device Address
☒ Loop 1 Address 1 ☐ Single Device
☐ Multiple Devices No. of devices 1

Device Type HEAT ANALOG Edit Custom Type

Device Label
 Adjective Noun
 Delete Custom Adjective/Noun Custom Label : SOUTH CLASSROOM

Device Options
☒ Device Enabled
☐ Pre-Signal Enabled
☐ PAS Enabled
☒ Device Walktestable
☐ Alarm Verification Enabled
☐ Device Silenceable
☐ MNS Override

Zone (0-49)
 Zone 1 0
 Zone 2
 Zone 3
 Zone 4
 Zone 5
 Zone 6
 Zone 7
 Zone 8
 Zone 9
 Zone 10
 Zone 11
 Zone 12
 Zone 13
 Zone 14
 Zone 15
 Zone 16
 Zone 17
 Zone 18
 Zone 19
 Zone 20
 Zone 21
 Zone 22
 Zone 23
 Zone 24
 Zone 25
 Zone 26
 Zone 27
 Zone 28
 Zone 29
 Zone 30
 Zone 31
 Zone 32
 Zone 33
 Zone 34
 Zone 35
 Zone 36
 Zone 37
 Zone 38
 Zone 39
 Zone 40
 Zone 41
 Zone 42
 Zone 43
 Zone 44
 Zone 45
 Zone 46
 Zone 47
 Zone 48
 Zone 49
 Zone 50
 Zone 51
 Zone 52
 Zone 53
 Zone 54
 Zone 55
 Zone 56
 Zone 57
 Zone 58
 Zone 59
 Zone 60
 Zone 61
 Zone 62
 Zone 63
 Zone 64
 Zone 65
 Zone 66
 Zone 67
 Zone 68
 Zone 69
 Zone 70
 Zone 71
 Zone 72
 Zone 73
 Zone 74
 Zone 75
 Zone 76
 Zone 77
 Zone 78
 Zone 79
 Zone 80
 Zone 81
 Zone 82
 Zone 83
 Zone 84
 Zone 85
 Zone 86
 Zone 87
 Zone 88
 Zone 89
 Zone 90
 Zone 91
 Zone 92
 Zone 93
 Zone 94
 Zone 95
 Zone 96
 Zone 97
 Zone 98
 Zone 99
 Zone 100
 Zone 101
 Zone 102
 Zone 103
 Zone 104
 Zone 105
 Zone 106
 Zone 107
 Zone 108
 Zone 109
 Zone 110
 Zone 111
 Zone 112
 Zone 113
 Zone 114
 Zone 115
 Zone 116
 Zone 117
 Zone 118
 Zone 119
 Zone 120
 Zone 121
 Zone 122
 Zone 123
 Zone 124
 Zone 125
 Zone 126
 Zone 127
 Zone 128
 Zone 129
 Zone 130
 Zone 131
 Zone 132
 Zone 133
 Zone 134
 Zone 135
 Zone 136
 Zone 137
 Zone 138
 Zone 139
 Zone 140
 Zone 141
 Zone 142
 Zone 143
 Zone 144
 Zone 145
 Zone 146
 Zone 147
 Zone 148
 Zone 149
 Zone 150
 Zone 151
 Zone 152
 Zone 153
 Zone 154
 Zone 155
 Zone 156
 Zone 157
 Zone 158
 Zone 159
 Zone 160
 Zone 161
 Zone 162
 Zone 163
 Zone 164
 Zone 165
 Zone 166
 Zone 167
 Zone 168
 Zone 169
 Zone 170
 Zone 171
 Zone 172
 Zone 173
 Zone 174
 Zone 175
 Zone 176
 Zone 177
 Zone 178
 Zone 179
 Zone 180
 Zone 181
 Zone 182
 Zone 183
 Zone 184
 Zone 185
 Zone 186
 Zone 187
 Zone 188
 Zone 189
 Zone 190
 Zone 191
 Zone 192
 Zone 193
 Zone 194
 Zone 195
 Zone 196
 Zone 197
 Zone 198
 Zone 199
 Zone 200
 Zone 201
 Zone 202
 Zone 203
 Zone 204
 Zone 205
 Zone 206
 Zone 207
 Zone 208
 Zone 209
 Zone 210
 Zone 211
 Zone 212
 Zone 213
 Zone 214
 Zone 215
 Zone 216
 Zone 217
 Zone 218
 Zone 219
 Zone 220
 Zone 221
 Zone 222
 Zone 223
 Zone 224
 Zone 225
 Zone 226
 Zone 227
 Zone 228
 Zone 229
 Zone 230
 Zone 231
 Zone 232
 Zone 233
 Zone 234
 Zone 235
 Zone 236
 Zone 237
 Zone 238
 Zone 239
 Zone 240
 Zone 241
 Zone 242
 Zone 243
 Zone 244
 Zone 245
 Zone 246
 Zone 247
 Zone 248
 Zone 249
 Zone 250
 Zone 251
 Zone 252
 Zone 253
 Zone 254
 Zone 255
 Zone 256
 Zone 257
 Zone 258
 Zone 259
 Zone 260
 Zone 261
 Zone 262
 Zone 263
 Zone 264
 Zone 265
 Zone 266
 Zone 267
 Zone 268
 Zone 269
 Zone 270
 Zone 271
 Zone 272
 Zone 273
 Zone 274
 Zone 275
 Zone 276
 Zone 277
 Zone 278
 Zone 279
 Zone 280
 Zone 281
 Zone 282
 Zone 283
 Zone 284
 Zone 285
 Zone 286
 Zone 287
 Zone 288
 Zone 289
 Zone 290
 Zone 291
 Zone 292
 Zone 293
 Zone 294
 Zone 295
 Zone 296
 Zone 297
 Zone 298
 Zone 299
 Zone 300
 Zone 301
 Zone 302
 Zone 303
 Zone 304
 Zone 305
 Zone 306
 Zone 307
 Zone 308
 Zone 309
 Zone 310
 Zone 311
 Zone 312
 Zone 313
 Zone 314
 Zone 315
 Zone 316
 Zone 317
 Zone 318
 Zone 319
 Zone 320
 Zone 321
 Zone 322
 Zone 323
 Zone 324
 Zone 325
 Zone 326
 Zone 327
 Zone 328
 Zone 329
 Zone 330
 Zone 331
 Zone 332
 Zone 333
 Zone 334
 Zone 335
 Zone 336
 Zone 337
 Zone 338
 Zone 339
 Zone 340
 Zone 341
 Zone 342
 Zone 343
 Zone 344
 Zone 345
 Zone 346
 Zone 347
 Zone 348
 Zone 349
 Zone 350
 Zone 351
 Zone 352
 Zone 353
 Zone 354
 Zone 355
 Zone 356
 Zone 357
 Zone 358
 Zone 359
 Zone 360
 Zone 361
 Zone 362
 Zone 363
 Zone 364
 Zone 365
 Zone 366
 Zone 367
 Zone 368
 Zone 369
 Zone 370
 Zone 371
 Zone 372
 Zone 373
 Zone 374
 Zone 375
 Zone 376
 Zone 377
 Zone 378
 Zone 379
 Zone 380
 Zone 381
 Zone 382
 Zone 383
 Zone 384
 Zone 385
 Zone 386
 Zone 387
 Zone 388
 Zone 389
 Zone 390
 Zone 391
 Zone 392
 Zone 393
 Zone 394
 Zone 395
 Zone 396
 Zone 397
 Zone 398
 Zone 399
 Zone 400
 Zone 401
 Zone 402
 Zone 403
 Zone 404
 Zone 405
 Zone 406
 Zone 407
 Zone 408
 Zone 409
 Zone 410
 Zone 411
 Zone 412
 Zone 413
 Zone 414
 Zone 415
 Zone 416
 Zone 417
 Zone 418
 Zone 419
 Zone 420
 Zone 421
 Zone 422
 Zone 423
 Zone 424
 Zone 425
 Zone 426
 Zone 427
 Zone 428
 Zone 429
 Zone 430
 Zone 431
 Zone 432
 Zone 433
 Zone 434
 Zone 435
 Zone 436
 Zone 437
 Zone 438
 Zone 439
 Zone 440
 Zone 441
 Zone 442
 Zone 443
 Zone 444
 Zone 445
 Zone 446
 Zone 447
 Zone 448
 Zone 449
 Zone 450
 Zone 451
 Zone 452
 Zone 453
 Zone 454
 Zone 455
 Zone 456
 Zone 457
 Zone 458
 Zone 459
 Zone 460
 Zone 461
 Zone 462
 Zone 463
 Zone 464
 Zone 465
 Zone 466
 Zone 467
 Zone 468
 Zone 469
 Zone 470
 Zone 471
 Zone 472
 Zone 473
 Zone 474
 Zone 475
 Zone 476
 Zone 477
 Zone 478
 Zone 479
 Zone 480
 Zone 481
 Zone 482
 Zone 483
 Zone 484
 Zone 485
 Zone 486
 Zone 487
 Zone 488
 Zone 489
 Zone 490
 Zone 491
 Zone 492
 Zone 493
 Zone 494
 Zone 495
 Zone 496
 Zone 497
 Zone 498
 Zone 499
 Zone 500
 Zone 501
 Zone 502
 Zone 503
 Zone 504
 Zone 505
 Zone 506
 Zone 507
 Zone 508
 Zone 509
 Zone 510
 Zone 511
 Zone 512
 Zone 513
 Zone 514
 Zone 515
 Zone 516
 Zone 517
 Zone 518
 Zone 519
 Zone 520
 Zone 521
 Zone 522
 Zone 523
 Zone 524
 Zone 525
 Zone 526
 Zone 527
 Zone 528
 Zone 529
 Zone 530
 Zone 531
 Zone 532
 Zone 533
 Zone 534
 Zone 535
 Zone 536
 Zone 537
 Zone 538
 Zone 539
 Zone 540
 Zone 541
 Zone 542
 Zone 543
 Zone 544
 Zone 545
 Zone 546
 Zone 547
 Zone 548
 Zone 549
 Zone 550
 Zone 551
 Zone 552
 Zone 553
 Zone 554
 Zone 555
 Zone 556
 Zone 557
 Zone 558
 Zone 559
 Zone 560
 Zone 561
 Zone 562
 Zone 563
 Zone 564
 Zone 565
 Zone 566
 Zone 567
 Zone 568
 Zone 569
 Zone 570
 Zone 571
 Zone 572
 Zone 573
 Zone 574
 Zone 575
 Zone 576
 Zone 577
 Zone 578
 Zone 579
 Zone 580
 Zone 581
 Zone 582
 Zone 583
 Zone 584
 Zone 585
 Zone 586
 Zone 587
 Zone 588
 Zone 589
 Zone 590
 Zone 591
 Zone 592
 Zone 593
 Zone 594
 Zone 595
 Zone 596
 Zone 597
 Zone 598
 Zone 599
 Zone 600
 Zone 601
 Zone 602
 Zone 603
 Zone 604
 Zone 605
 Zone 606
 Zone 607
 Zone 608
 Zone 609
 Zone 610
 Zone 611
 Zone 612
 Zone 613
 Zone 614
 Zone 615
 Zone 616
 Zone 617
 Zone 618
 Zone 619
 Zone 620
 Zone 621
 Zone 622
 Zone 623
 Zone 624
 Zone 625
 Zone 626
 Zone 627
 Zone 628
 Zone 629
 Zone 630
 Zone 631
 Zone 632
 Zone 633
 Zone 634
 Zone 635
 Zone 636
 Zone 637
 Zone 638
 Zone 639
 Zone 640
 Zone 641
 Zone 642
 Zone 643
 Zone 644
 Zone 645
 Zone 646
 Zone 647
 Zone 648
 Zone 649
 Zone 650
 Zone 651
 Zone 652
 Zone 653
 Zone 654
 Zone 655
 Zone 656
 Zone 657
 Zone 658
 Zone 659
 Zone 660
 Zone 661
 Zone 662
 Zone 663
 Zone 664
 Zone 665
 Zone 666
 Zone 667
 Zone 668
 Zone 669
 Zone 670
 Zone 671
 Zone 672
 Zone 673
 Zone 674
 Zone 675
 Zone 676
 Zone 677
 Zone 678
 Zone 679
 Zone 680
 Zone 681
 Zone 682
 Zone 683
 Zone 684
 Zone 685
 Zone 686
 Zone 687
 Zone 688
 Zone 689
 Zone 690
 Zone 691
 Zone 692
 Zone 693
 Zone 694
 Zone 695
 Zone 696
 Zone 697
 Zone 698
 Zone 699
 Zone 700
 Zone 701
 Zone 702
 Zone 703
 Zone 704
 Zone 705
 Zone 706
 Zone 707
 Zone 708
 Zone 709
 Zone 710
 Zone 711
 Zone 712
 Zone 713
 Zone 714
 Zone 715
 Zone 716
 Zone 717
 Zone 718
 Zone 719
 Zone 720
 Zone 721
 Zone 722
 Zone 723
 Zone 724
 Zone 725
 Zone 726
 Zone 727
 Zone 728
 Zone 729
 Zone 730
 Zone 731
 Zone 732
 Zone 733
 Zone 734
 Zone 735
 Zone 736
 Zone 737
 Zone 738
 Zone 739
 Zone 740
 Zone 741
 Zone 742
 Zone 743
 Zone 744
 Zone 745
 Zone 746
 Zone 747
 Zone 748
 Zone 749
 Zone 750
 Zone 751
 Zone 752
 Zone 753
 Zone 754
 Zone 755
 Zone 756
 Zone 757
 Zone 758
 Zone 759
 Zone 760
 Zone 761
 Zone 762
 Zone 763
 Zone 764
 Zone 765
 Zone 766
 Zone 767
 Zone 768
 Zone 769
 Zone 770
 Zone 771
 Zone 772
 Zone 773
 Zone 774
 Zone 775
 Zone 776
 Zone 777
 Zone 778
 Zone 779
 Zone 780
 Zone 781
 Zone 782
 Zone 783
 Zone 784
 Zone 785
 Zone 786
 Zone 787
 Zone 788
 Zone 789
 Zone 790
 Zone 791
 Zone 792
 Zone 793
 Zone 794
 Zone 795
 Zone 796
 Zone 797
 Zone 798
 Zone 799
 Zone 800
 Zone 801
 Zone 802
 Zone 803
 Zone 804
 Zone 805
 Zone 806
 Zone 807
 Zone 808
 Zone 809
 Zone 810
 Zone 811
 Zone 812
 Zone 813
 Zone 814
 Zone 815
 Zone 816
 Zone 817
 Zone 818
 Zone 819
 Zone 820
 Zone 821
 Zone 822
 Zone 823
 Zone 824
 Zone 825
 Zone 826
 Zone 827
 Zone 828
 Zone 829
 Zone 830
 Zone 831
 Zone 832
 Zone 833
 Zone 834
 Zone 835
 Zone 836
 Zone 837
 Zone 838
 Zone 839
 Zone 840
 Zone 841
 Zone 842
 Zone 843
 Zone 844
 Zone 845
 Zone 846
 Zone 847
 Zone 848
 Zone 849
 Zone 850
 Zone 851
 Zone 852
 Zone 853
 Zone 854
 Zone 855
 Zone 856
 Zone 857
 Zone 858
 Zone 859
 Zone 860
 Zone 861
 Zone 862
 Zone 863
 Zone 864
 Zone 865
 Zone 866
 Zone 867
 Zone 868
 Zone 869
 Zone 870
 Zone 871
 Zone 872
 Zone 873
 Zone 874
 Zone 875
 Zone 876
 Zone 877
 Zone 878
 Zone 879
 Zone 880
 Zone 881
 Zone 882
 Zone 883
 Zone 884
 Zone 885
 Zone 886
 Zone 887
 Zone 888
 Zone 889
 Zone 890
 Zone 891
 Zone 892
 Zone 893
 Zone 894
 Zone 895
 Zone 896
 Zone 897
 Zone 898
 Zone 899
 Zone 900
 Zone 901
 Zone 902
 Zone 903
 Zone 904
 Zone 905
 Zone 906
 Zone 907
 Zone 908
 Zone 909
 Zone 910
 Zone 911
 Zone 912
 Zone 913
 Zone 914
 Zone 915
 Zone 916
 Zone 917
 Zone 918
 Zone 919
 Zone 920
 Zone 921
 Zone 922
 Zone 923
 Zone 924
 Zone 925
 Zone 926
 Zone 927
 Zone 928
 Zone 929
 Zone 930
 Zone 931
 Zone 932
 Zone 933
 Zone 934
 Zone 935
 Zone 936
 Zone 937
 Zone 938
 Zone 939
 Zone 940
 Zone 941
 Zone 942
 Zone 943
 Zone 944
 Zone 945
 Zone 946
 Zone 947
 Zone 948
 Zone 949
 Zone 950
 Zone 951
 Zone 952
 Zone 953
 Zone 954
 Zone 955
 Zone 956
 Zone 957
 Zone 958
 Zone 959
 Zone 960
 Zone 961
 Zone 962
 Zone 963
 Zone 964
 Zone 965
 Zone 966
 Zone 967
 Zone 968
 Zone 969
 Zone 970
 Zone 971
 Zone 972
 Zone 973
 Zone 974
 Zone 975
 Zone 976
 Zone 977
 Zone 978
 Zone 979
 Zone 980
 Zone

Deleting Devices

When a device is no longer used, you can delete the device from the SLC Loop.

To delete the devices in the SLC loop

Select the check box corresponding to the device you want to delete in the **Detectors** screen. You can select multiple devices at a time.

Click **Delete Device** to delete the device from the SLC loop. A message asking for confirmation appears. Click **Yes** to delete the device details. The detector device is deleted from the SLC Loop.

[illegible]

Finding Devices

Using the **Search** option, you can find a device when there are multiple devices in the SLC loop. The **Search** option is available only with the **Tabular View**.

To find devices, select an option in **Field Type**. The available options are *Custom Label*, *Status*, *Address*, *Type*, *Verification*, *Walktest*, *Presignal*, *PAS*, *Sounder Base Installed*, *Coding*, *Sounder Base Volume*, *Wireless*, or *Sounder Base Silenceable*.

Select a **Value** from the drop-down list which corresponds to the selected **Field Type**.

Click **Search**. The search results are displayed in the **Tabular View**.

Click **Show All** to retrieve all the device records.

Loop	Address	Status	Type	Verification	Walktest	Presignal	PAS	Custom Label	SounderBase Installed	Coding
1	4	Enable	BEAM	False	True	False	False		False	

Click **Save to Database** to save the configuration in the FS-Tools database.

Click **Next** or click **Modules** in **SLC Loop Setup** in the left pane, to view the **SLC Loop Setup -> Modules** pane.

Click **Prev** to go back to the **Secondary ANN-Bus** configuration pane.

Device Address

In **Device Address**, specify the device address between 1 to 50.

To add only one device, click **Single Device**.

To add more than one device, click **Multiple Devices** and specify the number of devices you want to add in **No. of devices**. The **device address** will be the address for the first device. The next devices will have consecutive addresses.

You will get an error message if you select an invalid address.

Detector Device Type

Select the **Device Type** from the drop-down box. Available types are:

Detector Type	Action When Activated
Smoke Photo	Fire Alarm
User-Defined-1	same as previous (Smoke Photo)
Smoke Ion	Fire Alarm
User-Defined-2	same as previous (Smoke Ion)
Heat Detect	Fire Alarm
User-Defined-3	same as previous (Heat Detect)
Smoke Duct-P	Fire Alarm
User-Defined-4	same as previous (Smoke Duct-P)
Photo w/Heat	Fire Alarm
User-Defined-5	same as previous (Photo w/Heat)
Duct Superv	Supervisory, latching
User-Defined-7	same as previous (Duct Superv)
Photo-Super AR	Supervisory, nonlatching (works only in LiteSpeed)
User-Defined-8	same as previous (Photo-Super AR)
ADAPT	Fire Alarm
User-Defined-10	same as previous (ADAPT)
Beam	Fire Alarm
User-Defined-11	same as previous (Beam)
Fire/CO	response is programmable (Alarm, Supv, or None)
User-Defined-12	same as previous (Fire/CO)

To add a user defined device type, select *USER-DEF-1* from the list, and click **Edit Custom Type**. Enter the new type label in the displayed window and click **OK**.

In **Device Label**, select the **Adjective** and the **Noun** which specify the device location. The adjective and noun are specific descriptors to identify the device location. To add a custom adjective/noun, select the *Add New* option from the adjective/noun list and specify the custom adjective/noun in the displayed window. **Custom Label** displays the selected **Adjective** and **Noun**.

Detector Device Options

In **Device Options**, the **Device Enabled** option is selected by default (when you click Add Device). If this option is not selected, the detector is not polled by the control panel, which prevents the detector from reporting alarms and troubles to the panel. The control panel displays the device type and address of the disabled device and activates the Trouble and Disable LEDs.

To enable the Pre-Signal option for the device, click **Pre-Signal Enabled**. This option programs the detector to delay panel activation for a pre-programmed time delay of up to three minutes, while allowing for visual verification. The alarm relay and communicator respond to the initial alarm immediately. In addition, Zone 48 activates immediately and can be programmed to a control module, to activate a sounder or indicator designated for Pre-signal indication (*do not use a Notification Appliance Circuit for this purpose*).

To enable the PAS option for the device, click **PAS Enabled**. The PAS option programs the detector to delay panel activation (including alarm relay and communicator) for a period of fifteen seconds plus a programmable time of up to three minutes. Zone 47, however, activates immediately and can be used to connect a signaling device to indicate PAS activation (*do not use a Notification Appliance Circuit for this purpose*).

Note: For a device, you can enable the PAS option or the Pre-Signal option. You cannot enable both options together.

The **Device Walktestable** option is selected by default. The Walktest feature allows you to test the system devices without manually resetting the control panel after each device activation.

To enable the Alarm Verification option for the device, click **Alarm Verification Enabled**. Alarm verification is used to confirm that a smoke detector activation is a true alarm condition and not a false alarm.

You can map each device to five **Zones**. Enter the three digit number corresponding to the zone assigned to the device for **Zone 1** to **Zone 5**. The factory default for an unprogrammed device is *Z000* for a general alarm zone.

Enter the **Additional Information** about the detector being programmed. This information is displayed as part of the device label on the panel display.

Note: The **Device Silenceable** option is disabled for the detectors.

Sounder Base Options

If the selected detector is installed in a Sounder Base, ensure that the **Sounder Base Installed** option checkbox is selected.

To enable the sounder base at this address, select the **Sounder Base Enabled** checkbox.

Coding: from the drop-down box, select the output type desired from the sounder base. The following options are available:

- **Steady** - a continuous output with no coding
- **Temporal 3** - ½ Second On, ½ Second Off, ½ Second On, ½ Second Off, ½ Second On, 1½ Seconds Off
- **Temporal 4** - ½ Second On, ½ Second Off, ½ Second On, ½ Second Off, ½ Second On, ½ Second Off, ½ Second On, 1½ Seconds Off
- **March Time** - 120 ppm (pulse-per-minute) output

Volume: from the drop-down box, select the sounder base output volume. Available settings are **Low**, **Medium**, and **High**.

Zones: You can map each Sounder Base to five **Zones**. Enter the three digit number corresponding to the zone assigned to the device for **Zone 1** to **Zone 5**. The factory default for an unprogrammed device is *Z000* for a general alarm zone.

Wireless Option

If the selected device is a wireless device, part of the SWIFT® Wireless System, select the **Wireless** checkbox.

For more information on the SWIFT Wireless system, refer to Document number #LS10036-000FL-E on www.firelite.com.

Modules

From the detectors screen, you can:

- [Add](#) a new addressable module to the SLC loop.
- View the added modules in a [tabular](#) or [graphical](#) form
- [Edit](#) the programming for an existing module.
- [Delete](#) an existing module from the loop.
- [Search](#) for modules in a zone.

[illegible]

Adding Devices

From the bottom of the detector screen, select the Add Device(s) button. The following screen appears. See following pages to learn more.

Add

SLC Setup -> Device Settings -> Modules

Device Address

☒ Loop1 Address: ☒ Single Device

☐ Multiple Devices No. of devices:

Device Type PULL STATION Edit Custom Type

Device Label

Adjective: Noun:

Delete Custom Adjective/Noun Custom Label:

Device Options

☒ Device Enabled ☐ Control Module Delay Timer Enabled

☐ Pre-Signal Enabled

☐ PAS Enabled

☒ Device Walktestable

☐ Alarm Verification Enabled

☐ Device Silenceable

Zone (0-49)

Zone 1: Zone 2:

Zone 3: Zone 4:

Zone 5:

Wireless Option

☐ Wireless

Additional Info:

OK Cancel


Click OK when finished and the device(s) will appear on the module screen.

Viewing Devices

There are two ways the devices can be viewed. There is a **tabular view** which outlines the device information in a table view.

	Loop	Address	Status	Type	Silenceable	Walktest	Presignal	PAS	Delay Timer	Device Installed	Wireless
<input checked="" type="checkbox"/>	1	11	Enable	WATER FLOW	False	True	False	False	False	True	Disable
<input type="checkbox"/>	1	12	Enable	PULL STATION	False	True	False	False	False	True	Disable
<input type="checkbox"/>	1	13	Enable	MONITOR	False	True	True	False	False	True	Enable
<input type="checkbox"/>	1	21	Enable	CONTROL	True	True	False	False	False	True	Disable
<input type="checkbox"/>	1	22	Enable	CONTROL	True	True	False	False	True	True	Disable
<input type="checkbox"/>	1	23	Enable	CONTROL	True	True	False	False	True	True	Disable
<input type="checkbox"/>	1	24	Enable	CONTROL	True	True	False	False	False	True	Disable
<input type="checkbox"/>	1	31	Enable	PULL STATION	False	True	False	False	False	True	Disable
<input type="checkbox"/>	1	32	Enable	PULL STATION	False	True	False	False	False	True	Disable
<input type="checkbox"/>	1	33	Enable	PULL STATION	False	True	False	False	False	True	Disable
<input type="checkbox"/>	1	34	Enable	PULL STATION	False	True	False	False	False	True	Disable
<input type="checkbox"/>	1	35	Enable	PULL STATION	False	True	False	False	False	True	Disable
<input type="checkbox"/>	1	36	Enable	PULL STATION	False	True	False	False	False	True	Disable
<input type="checkbox"/>	1	37	Enable	PULL STATION	False	True	False	False	False	True	Disable
<input type="checkbox"/>	1	41	Enable	MONITOR	False	True	True	False	False	True	Disable
<input type="checkbox"/>	1	42	Enable	MONITOR	False	True	True	False	False	True	Disable
<input type="checkbox"/>	1	43	Enable	MONITOR	False	True	True	False	False	True	Disable
<input type="checkbox"/>	1	44	Enable	MONITOR	False	True	True	False	False	True	Disable

The **graphical view** offers a pictorial view of the devices on the loop.



Editing Devices

Using the **Edit Devices** option, you can edit the device type, device options, and change the zone mapping.

Select the check box corresponding to the device you want to edit in the **Modules** screen. You can select only one device at a time.

Click **Edit Device(s)** to edit the device information. The **Edit** dialog box appears.

The screenshot shows the 'Edit' dialog box with the title bar 'Edit'. The main window has a title bar 'SLC Setup -> Device Settings -> Modules'. The dialog is divided into several sections:

- Device Address:** Includes a radio button for 'Loop1' (selected) and a text field for 'Address' containing '1'. There are also radio buttons for 'Single Device' (selected) and 'Multiple Devices' (disabled), with a 'No. of devices' text field set to '1'.
- Device Type:** A dropdown menu showing 'PULL STATION' and a button 'Edit Custom Type'.
- Device Label:** Includes dropdowns for 'Adjective' and 'Noun', a 'Delete Custom Adjective/Noun' button, and a 'Custom Label' text field.
- Device Options:** A group box containing several checkboxes: 'Device Enabled' (checked), 'Control Module Delay Timer Enabled' (unchecked), 'Pre-Signal Enabled' (unchecked), 'PAS Enabled' (unchecked), 'Device Walktestable' (checked), 'Alarm Verification Enabled' (unchecked), and 'Device Silenceable' (unchecked).
- Zone (0-49):** A list of five zones with corresponding text fields: 'Zone 1' (0), 'Zone 2', 'Zone 3', 'Zone 4', and 'Zone 5'.
- Wireless Option:** A checkbox labeled 'Wireless' which is unchecked.
- Additional Info:** A large text area at the bottom.
- Buttons:** 'OK', 'Cancel', and 'Edit All Selected Points' at the bottom.

Update the device information such as **Device Type**, **Device Label**, **Device Options**, **Zone** assignments, and **Wireless** participation.

Click **OK**. The device information is updated in SLC loop setup.

Note: You cannot modify the device address using the **Edit Device** option.

Deleting Devices

When a device is no longer used, you can delete the device from the SLC Loop.

To delete the devices in the SLC loop

Select the check box corresponding to the device you want to delete in the **Modules** screen. You can select multiple devices at a time.

Click **Delete Device** to delete the device from the SLC loop. A message asking for confirmation appears. Click **Yes** to delete the device details. The module device is deleted from the SLC Loop.

[illegible]

Finding Devices

Using the **Search** option, you can find a device when there are multiple devices in the SLC loop. The **Search** option is available only with the **Tabular View**.

To find devices, select an option in **Field Type**. The available options are *Custom Label, Status, Address, Type, Silenceable, Walktest, Presignal, PAS, Wireless, and Control Module Delay Timer Enabled*.

Select a **Value** from the drop-down list which corresponds to the selected **Field Type**.

Click **Search**. The search results are displayed in the **Tabular View**.

Click **Show All** to retrieve all the device records.

Loop	Address	Status	Type	Silenceable	Walktest	Presignal	PAS	Control Module DelayTimer	Wireless	MNS Override
1	4	Enable	CONTROL	True	True	False	False	False	Disable	False

Click **Save to Database** to save the configuration in the FS-Tools database.

Click **Save as Template** to save the configuration as a template. The saved template can be used for configuring other fire panels using the same computer or laptop. Type the new **Template Name** in the save as dialog box, then click **Save**, to save the fire panel configuration as a template.

Click **Next** or click **Verify Setup** in the left pane, to check input/output mapping.

Click **Prev** to go back to the **Detectors** pane.

Device Address

In **Device Address**, specify the device address between 1 to 50.

To add only one device, click **Single Device**.

To add more than one device, click **Multiple Devices** and specify the number of devices you want to add in **No. of devices**. The **device address** will be the address for the first device. The next devices will have consecutive addresses.

You will get an error message if you select an invalid address.

Module Device Type

Device types tell the panel what function each module will perform. Separate type codes are available for [Monitor Modules](#) and [Control Modules](#).

Monitor Module Types

Select the **Monitor Device Type** from the drop-down box. Available types are:

Monitor Type	Action When Activated
Pull Station	Fire Alarm
User-Defined-1	same as previous (Pull Station)
Waterflow	Fire Alarm Delayed
User-Defined-2	same as previous (Waterflow)
Monitor	Fire Alarm
User-Defined-3	same as previous (Monitor)
Future	not used
Future	not used
Smoke-Conventional	Fire Alarm
User-Defined-5	same as previous (Smoke-Conventional)
Heat-Conventional	Fire Alarm
User-Defined-6	same as previous (Heat-Conventional)
Medic-Alert	General Purpose Signaling, latching
User-Defined-7	same as previous (Medic-Alert)
Hazard-Alert	General Purpose Signaling, latching
User-Defined-8	same as previous (Hazard-Alert)
Tornado-Alert	General Purpose Signaling, latching
User-Defined-9	same as previous (Tornado-Alert)
Phone	Active Phone (LCD display only)
User-Defined-10	same as previous (Phone)
Tamper	Supervisory, nonlatching (tracking)
User-Defined-11	same as previous (Tamper)
Supervisory	Supervisory, latching

User-Defined-12	same as previous (Supervisory)
Supervisory-AR	Supervisory, nonlatching (tracking)
User-Defined-13	same as previous (Supervisory-AR)
HVAC OVRIDE	Switch Supervisory, nonlatching (tracking)
Power-Monitor	Power Fault
User-Defined-14	same as previous (Power Monitor)
Trouble-Monitor	Trouble
User-Defined-15	same as previous (Trouble Monitor)
Process-Monitor	General Purpose Signaling, latching
User-Defined 16	same as previous (Process-Monitor)
Process-Monitor-AR	General Purpose Signaling, nonlatching (tracking)
User-Defined 17	same as previous (Process-Monitor-AR)
Ack-Switch	Acts like panel Acknowledge Key
Sil Switch	Acts like panel Silence Key
Reset Switch	Acts like panel Reset Key
Drill Switch	Acts like panel Drill Key
PAS Bypass HVAC	PAS Disable
RESTART Drill	Switch
Switch AR	Acts like panel Drill Key, nonlatching (tracking)
Wireless Gateway	Reports wireless gateway troubles to the FACP (Using this type code replaces the need for a remote annunciator/display driver on the SWIFT network.)

To add a user defined device type, select *USER-DEF-1* from the list, and click Edit Custom Type. Enter the new type label in the displayed window and click OK.

Control Module Types

Select the **Control Device Type** from the drop-down box. Available types are:

Monitor Type	Action When Activated
Bell Circuit	NAC Type- supervised
Horn Circuit	NAC Type- supervised
Sounders	NAC Type- supervised
Relay	Relay Type- Ignore open circuit
Strobe Circuit	NAC Type- supervised
Control	NAC Type- supervised
Resettable Power	Relay Type- Ignore open circuit
HVAC Shutdown RLY	Relay Type- Ignore open circuit
HVAC Shutdown NAC	NAC Type- supervised

In **Device Label**, select the **Adjective** and the **Noun** which specify the device location. The adjective and noun are specific descriptors to identify the device location. To add a custom adjective/noun, select the *Add New* option from the adjective/noun list and specify the custom adjective/noun in the displayed window. **Custom Label** displays the selected **Adjective** and **Noun**.

Module Device Options

In **Device Options**, the **Device Enabled** option is selected by default (when you click Add Device). If this option is not selected, the module is not polled by the control panel, which prevents the module from reporting alarms and troubles to the panel. The control panel displays the device type and address of the device disabled and activates the Trouble and Disable LEDs.

To enable the Pre-Signal option for a module, click **Pre-Signal Enabled** option. The Pre-signal option programs the module to delay panel activation for a pre-programmed time delay of up to three minutes while allowing for visual verification. Set the delay time on the [General System Settings](#) Page.

Note: The **PAS Enabled**, **Alarm Verification Enabled**, and **Device Silenceable** options are disabled for modules.

The **Device Walktestable** option is selected by default. The Walktest feature allows you to test the system devices without manually resetting the control panel after each device activation.

The Delay Timer Enabled feature is only applicable to Control Modules. When enabled, this timer delays activation of the selected control module after being triggered by an alarm condition. Delay time varies from 0-180 seconds. Set the delay time on the [General System Settings](#) Page.

You can map each device to five **Zones**. Enter the three digit number corresponding to the zone assigned to the device for **Zone 1** to **Zone 5**. The factory default for an unprogrammed device is **Z000** for a general alarm zone.

Enter the **Additional Information** about the detector being programmed. This information is displayed as part of the device label on the panel display.

Wireless Option

If the selected device is a wireless device, part of the SWIFT® Wireless System, select the **Wireless** checkbox.

For more information on the SWIFT Wireless system, refer to Document number #LS10036-000FL-E on www.firelite.com.

Verify Setup




















The **Verify Setup** feature checks to see whether each input device is programmed to at least one output device and vice versa. This feature verifies the loop configuration and displays a warning message if there is a mismatch.

Click **Verify Setup** to check the mapping of the input and output devices.

If there is a proper mapping between each input device and output device, a message appears to indicate there are no warnings in verification.



A warning is displayed listing if all the detector devices and monitor modules are not connected to an output/input device.

#	Type	Description
1		Detector 1 on Loop1 has Z5 not connected to any output device
2		Detector 1 on Loop1 has Z6 not connected to any output device
3		Detector 2 on Loop1 has Z5 not connected to any output device
4		Detector 2 on Loop1 has Z6 not connected to any output device
5		Detector 3 on Loop1 has Z5 not connected to any output device
6		Detector 3 on Loop1 has Z6 not connected to any output device
7		Detector 4 on Loop1 has Z5 not connected to any output device
8		Detector 4 on Loop1 has Z6 not connected to any output device
9		Detector 5 on Loop1 has Z5 not connected to any output device
10		Detector 5 on Loop1 has Z6 not connected to any output device
11		Detector 6 on Loop1 has Z5 not connected to any output device
12		Detector 6 on Loop1 has Z6 not connected to any output device
13		Monitor Module 1 on Loop1 has Z1 not connected to any output device
14		Monitor Module 1 on Loop1 has Z2 not connected to any output device
15		Monitor Module 1 on Loop1 has Z3 not connected to any output device
16		Monitor Module 1 on Loop1 has Z4 not connected to any output device
17		Monitor Module 2 on Loop1 has Z1 not connected to any output device
18		Monitor Module 2 on Loop1 has Z2 not connected to any output device
19		Monitor Module 2 on Loop1 has Z3 not connected to any output device


Click **Print** if you want to create a PDF file of the verification errors.


Click **Next** or click **Simulation -> Tabular View** in the left pane, to view the **Simulation** screen.

Click **Prev** to go back to the **SLC Loop Setup -> Modules** pane

Tabular View

Click the address of an input device to view the output correlations or click the address of an output device to view the input correlations.





The Output devices are denoted by >> in the displayed **Results**.

Click **Refresh** to refresh the displayed results when you select another detector.

Click **Stop Simulation** to stop the simulation.


Graphical View

To perform simulation in graphical view:

Click **Graphical View** under **Simulation** in the left pane.

To view the devices mapped to a specific zone, click **Show Devices Mapped to Zone#**.

Enter the zone number.




Click **Show** to display the detectors and modules mapped to the selected zone.

Click **Refresh Grid** to restore the normal display.

Click **Stop**.

To view the device-to-device mapping, click **Show Device-to-Device I/O Simulation**.



Click **Show** to display the output devices mapped to a selected input device.

Upload Information

The uploaded information displays all the configuration information retrieved from the fire panel to the computer, using FS-Tools. In addition to the configuration information, the following data can be uploaded from the fire panel.

[Walktest Data](#)

[History Data](#)

[System Status Data](#)

The uploaded information from the fire panel helps to monitor troubles, alarms, and other fire panel events.

Walktest Data

Walktest is a feature which allows you to test the fire alarm system. The walktest data displays the time and date of events at various zones in the fire alarm system, after you conduct a walktest.

[illegible]

History Data

The history data lists all the events and event types such as alarms, troubles, activations, and other information with the date and time of occurrence.

Upload Information -> History

#	Event	Description	Event Type	Time Date	Device Address
3		UPLOAD SUCCESS		12:26 271117	
4		UPDOWN REQUEST		13:51 271117	
5	DNLOAD IN SYSTEM	ZONE SETUP		13:51 271117	
6		DOWNLOAD SUCCESS		13:51 271117	
7	DNLOAD IN SYSTEM	DACT CONFIGURATION		13:51 271117	
8		DOWNLOAD SUCCESS		13:51 271117	
9		DOWNLOAD SUCCESS		13:51 271117	
10	DNLOAD IN SYSTEM	SYSTEM PROGRAMMING		13:51 271117	
11		DOWNLOAD SUCCESS		13:51 271117	
12	DNLOAD IN SYSTEM	POINT PROGRAMMING		13:52 271117	
13		DOWNLOAD SUCCESS		13:52 271117	
14	TROUBL IN SYSTEM	OFF NORMAL MESSAGE		01:01 010117	
15	TROUBL IN SYSTEM	REMOTE SYNC FAULT		01:01 010117	
16	TROUBL IN SYSTEM	NO BATTERY		01:01 010117	
17	TROUBL IN SYSTEM	ANN-SEC COMM FAULT		01:01 010117	
18	TROUBL IN SYSTEM	ANN-PRI COMM FAULT		01:01 010117	
19	TROUBL IN SYSTEM	CELLULAR FAULT		01:01 010117	
20	Normal IN SYSTEM	OFF NORMAL MESSAGE		01:03 010117	
21	DISABL SMOKE(PHOTO)	NORTH ELEVATOR		01:03 010117	1D001
22	DISABL SUPERV DUCTP	FRONT OFFICE		01:03 010117	1D011
23	DISABL PHOTO SUP AR	CENTER GARAGE		01:03 010117	1D013
24	DISABL BEAM	CENTER GARAGE		01:03 010117	1D017
25	DISABL MONITOR	FRONT CORRIDOR		01:03 010117	1D019

Print History

<< Prev Next >>

System Status Data

The system status data displays the detector sensitivity data and LED and piezo status of the panel.

Upload Information -> System Status Data

Detector Sensitivity Data

Loop No.	Detector No.	Detector Type	Sensitivity Level	%Obs / Temperature
1	1	HEAT DETECT	6	88(190 F)
1	3	SMOKE (ION)	5	1.50
1	5	SMOKE (ION)	5	1.50
1	8	SMOKE(PHOTO)	6	1.66
1	9	SMOKE (ION)	5	1.50
1	10	SMOKE (ION)	5	1.50
1	11	SMOKE (ION)	5	1.50
1	13	SMOKE (ION)	5	1.50

Print Detector Data

LED and Piezo Status

Fire Alarm

CO Alarm

ACK

Alarm Silence

Drill

AC Power

Battery

Supervisory

Disabled

Trouble

Communication

Ground

Maintenance

* Piezo Status : On

F1

F2

F3

F4

<< Prev


File Menu

Changing Download Password

To download the configuration data to the fire panel, you must connect the computer to the fire panel. In FS-Tools, you can change the download password for downloading the configuration data to the fire panel, only if you have administrator rights.

Note: You must add at least one customer record before changing the download password.

In the **File** menu in the initial customer screen, click **Change Download Password**. The **Change Password** window appears.

A screenshot of a Windows-style dialog box titled "Change Password". The dialog box has a light gray background and a blue title bar with a close button (X) in the top right corner. It contains three text input fields stacked vertically. The first field is labeled "Old Download Password", the second is labeled "New Download Password", and the third is labeled "Confirm Download Password". Below the input fields are two buttons: "OK" on the left and "Close" on the right.

Type the **Old Password**.

Type the **New Password**, and then retype the password in **Confirm Password**.

Click **OK**. The download password is changed.


Template Menu

Delete a Template

A configuration template can be deleted when it is no longer needed.

To delete a template, choose **Template > Delete Template** in the initial customer screen in FS-Tools.

The **Delete Template** dialog box appears.



Select the template from the list displayed in **Existing Templates**.

Click **Delete Template**. This deletes the configuration template.

Note: The factory default template cannot be deleted.

Tools Menu

Compare Configuration

The **Compare Configuration** option shows the differences in fire panel configurations for two different customers or two different configurations for the same customer.

To compare two configurations, click **Tools > Compare Configuration** in the initial customer screen in FS-Tools. The **Compare Configuration** dialog box appears.

Select **Customer1** and **Customer2**.

Select the **Configuration** for **Customer1** and **Customer2**.

Click **Compare**. The **Compare Results** dialog box displays the compared **System Configuration** data for the two customers.

Feature Description	File1	File2
- Central Station		
Communicator Enabled	True	True
Test Time Interval	24 Hours	24 Hours
Test Time	0100	0100
Trouble Call Limit	00	00
Reporting Style	Point	Point
PhoneLine 1 Enable	True	True
PhoneLine 2 Enable	True	False
Dialing Gain	NORMAL	NORMAL
Reporting Gain	NORMAL	NORMAL
PhoneLine1 Supervision Enable	False	False
PhoneLine2 Supervision Enable	False	False
Phone Line 1 TouchTone/Rotary	Touch Tone	Touch Tone
PhoneLine 2 TouchTone/Rotary	Touch Tone	Touch Tone
DHCP Enable	True	True
IP Address	0.0.0.0	0.0.0.0
IP DNS	0.0.0.0	0.0.0.0
Gateway Address	0.0.0.0	0.0.0.0
Subnet Mask	0.0.0.0	0.0.0.0


Using the Compare Results dialog box, you can also perform the following.

- Click **Expand All** for an expanded view of all the configuration data in **System Configuration** tab.
- Click **Collapse All** for an collapsed view of all the configuration data in **System Configuration** tab.

- Click **Show Differences** to view the differences in the configuration data in the **System Configuration** tab.
- Click the **Detectors**, **Modules**, **Zones**, or **EventCodes** tabs to view the configuration data.
- Click **Select Other Files** to select another customer for configuration.
- Click **Show All** to view the configuration details of both the customers.
- Click **Print** to generate a *PDF* file.

Database Backup

To save a backup of the database, click **Tools > Database Backup** in the initial customer screen in FS-Tools. The **Save Database As** dialog box appears.




Select the folder to save the database backup.

Click **Save**. The database backup is saved in the selected folder.

Restore Backup


There can be situations where the current working database encounters problems. In such cases you can restore a backup of the working database. You can restore the database that was last backed up to ensure minimum data loss.

To restore the database, click **Tools > Restore Backup** in the initial customer screen in FS-Tools. The **File Type** dialog box appears.



Select the database file to restore and click **Open**.

A message informing you about the application being closed is displayed.



Click **OK**. FS-Tools will automatically close and need to be restarted.

Export a Configuration


The export configuration option is used when the same configuration needs to be used for configuring a fire panel, in another location with a different computer. The exported configuration can be saved onto a floppy disk or a CD-ROM and reused.

You can export the configuration in two ways:

- Export To [Excel](#)
- Export To [Disk](#)

Export to Excel

To export the configuration to an excel sheet, choose **Tools > Export > Export To Excel** in the initial customer screen in FS-Tools. The **Export Selected Configuration As** dialog box appears.




Select the folder in which the exported configuration will be saved.

Click **Save**. A message indicating that the details are successful exported is displayed.



Export to Disk

To export the configuration to a disk, choose **Tools > Export > Export To Disk** in the initial customer screen in FS-Tools. The **Export Selected Configuration As** dialog box appears.




Select the folder in which the exported configuration will be saved.

Click **Save** to save the configuration information in the binary format. A message indicating that the details are successful exported is displayed.


Import a Configuration

You can import configuration details from the panel to FS-Tools.

To import a configuration, choose **Tools > Import** in the initial customer screen in FS-Tools. The **Import Configuration From** dialog box appears.



Select a configuration file and then click **Open**. The configuration details are imported in the binary format. A message, prompting you to save the configuration details to the database is displayed.




Click **Yes** to save the details to the database.


Import All Configurations

Using FS-Tools, You can import and update all the configuration details from to the FS-Tools database without modifying the existing information.

To import all the configurations, choose **Tools > Import All** from the initial customer details window in FS-Tools. The **Import Database from** dialog box appears.



Select the configuration files, and then click **Open**. The configuration details are updated. After updating the configuration details, a message appears, prompting you to restart the application, to view the changes.



Click **OK**.

Get Write Access

Modifying Customer Details

You can modify or view the customer details from the database server. To modify, you need to obtain write permission. To view, a read-only permission is sufficient.

To obtain write permission:

Select a **Customer**.

Choose **Tools > Get Write Access** in the initial customer screen in FS-Tools. A message, indicating the status for obtaining the write permission, appears. If the customer details are currently modified by another user, you might get only a read-only access. Try again after some time to obtain the write access.

After obtaining the write permission, click **Configure** in the initial customer screen in FS-Tools, to modify the configuration settings.

Note: If you click **Tools->Get Write Access** on a computer running Windows ®7/ Windows ® Vista/Windows ® XP SP2, the networked computer does not display any message. This is applicable only to Custom Setup.

To view the configuration details:

Select and double-click a **Customer**. A message asking for confirmation appears.

Click **OK** to view the customer details in read only mode.


Run from Database

Using FS-Tools, you can connect to the database installed on your computer (client database or to the database installed on a remote computer (server database).

Note: If you have installed the client and the server on the same computer, then your computer acts as both client and server.


To Connect to the Server Database

Choose **Tools > Run from Database > Server Machine** from the initial customer details window in FS-Tools. The **Server Machine** dialog box appears.



In the **Enter the IP Address or Machine Name of the Server** text box, type the IP address or the machine name of the computer on which you have installed the database.


Click **OK**. A message informing you about the application being restarted, is displayed.



Click **OK**. The details of the server database are listed in the initial customer window in FS-Tools.

To Connect to the Client Database

Choose **Tools > Run from Database > Client Machine** from the initial customer details window in FS-Tools. A message appears, informing you about the path where you have installed the client database.




Click **OK** to restore the client database.

Last Configuration Date

Using FS-Tools, you can view the details of a particular customer such as configuration date, when there are multiple customers with the same name, panel type, etc.

To view the configuration date, select the Customer.

Click **Tools > Last Configuration Date** from the initial customer details window in FS-Tools. The **Last Configuration Date** dialog box appears, displaying the details of the particular customer.



Click **OK**.

Upload/Download Menu

Upload/Download Configuration Data

The configuration process is completed only when you download the saved configuration to the fire panel. Using the Upload/Download option in FS-Tools, you can:

- [Download](#) saved configuration and other panel settings to the fire panel.
- [Upload](#) Configuration Data, History Data, Walktest Data, Troubleshoot Data, System Status, and Point Status information from the fire panel to the computer.
- [View](#) all the uploaded data from the fire panel to monitor the fire alarm system and identify troubles, alarms, and other events.

Ensure the fire panel remains in the 'System Normal' state when you download or upload data to and from the fire panel. You can connect the computer to the fire panel using a USB port, or ethernet connection.


Upload/Download

Download Configuration Data to the FACP

Using the **Download to Panel** option, you can download the Point Programming, Communicator, Event Codes, Zones, General System Settings, ANN-Bus, Date and Time configuration data to the fire panel. When you download data for the first time, ensure that *all* the configuration data are downloaded to the fire panel.

To download the configuration information to the fire panel, click **Upload/Download > Upload/Download** from the initial customer details window in FS-Tools. The upload/download window opens.

Ensure that the FACP is available to accept downloads by pressing **Menu** on the FACP keypad. Then select option **3=FS TOOL UP/DOWNLOAD**. Otherwise, configuration download requests will be denied at the panel.




1. Select the **Communication Mode** from the drop-down menu. FS-Tools can connect **directly** with the FACP using a USB cable or **remotely** with an Ethernet connection to the IPOTS-COM communicator.
2. In the **Download to Panel** section of the window, you can select individual options to download (Point Programming, DACT, Event Codes, Zones, System Programming, Options, ANN-Bus, and Date and Time configuration data) or select **all configuration data** to send all information to download to the fire panel.
3. Click **Download to panel**.

4. Click **Clear Display** to clear the display of the status information in **PC Panel Communication Status**.

When the download is complete, the status that the configuration data is saved in the database is displayed in **PC Panel Communication Status**.

5. Click **Close** to close the **Upload/Download** dialog box after the upload/download process is completed.

If after clicking **Download to Panel**, the panel version does not match the FS-Tools version on the computer, a message asking you to view the difference in features appears.



Click **Yes**. The **Difference in Upload/Download** window appears.

FS-Tools Programming Guide for the ES-50X Series FACPs

Difference in Upload/Download

Customer

Paul Chadbourne

Panel Type

50 Pt Addr.

System Configuration

Device Types

Event Codes

Feature Description	Value Configured In FS-Tools	Value Uploaded/Downloaded
Ann Bus Enabled	False	Feature N/A for target panel
Ann Printer Options	Serial	Feature N/A for target panel
Ann Serial Baud	9600	Feature N/A for target panel
Ann Serial Bits	7	Feature N/A for target panel
Ann Parity Bits	Even	Feature N/A for target panel
Ann Stop Bits	1	Feature N/A for target panel
Ann SPG Timer	60	Feature N/A for target panel
Ann Printer Supervision	True	Feature N/A for target panel
Piezo Enable	True	Feature N/A for target panel
Lock Enable	True	Feature N/A for target panel
Ack Enable	True	Feature N/A for target panel
Silence Enable	True	Feature N/A for target panel
Reset Enable	True	Feature N/A for target panel
Drill Enable	True	Feature N/A for target panel
Primary Ann Address	Not Installed	Feature N/A for target panel
Primary Ann Address	Not Installed	Feature N/A for target panel
Primary Ann Address	Not Installed	Feature N/A for target panel
Primary Ann Address	Not Installed	Feature N/A for target panel
Primary Ann Address	Not Installed	Feature N/A for target panel
Primary Ann Address	Not Installed	Feature N/A for target panel
Primary Ann Address	Not Installed	Feature N/A for target panel
Primary Ann Address	Not Installed	Feature N/A for target panel
Secondary Phone Line Supervision	Enabled	Feature N/A for target panel

Print

In the **System Configuration** tab, you can view the information such as name of the feature, the value assigned to the feature in FS-Tools, and the values downloaded to the panel. Click **Print** to generate a PDF file.

Note: If the feature configured in FS-Tools is not present in the panel, a message is displayed corresponding to the value in FS-Tools.

Download Configuration Data to the FACP

[illegible]

In the **Device Types** tab, you can view the information such as loop, address, name of the device, the value assigned to the feature in FS-Tools, and values downloaded to the panel. Click **Print** to generate a PDF file.

FS-Tools Programming Guide for the ES-50X Series FACP's

Difference In Upload/Download

Customer: Panel Type:

System Configuration | Device Types | **Event Codes**

Value Configured/Uploaded/Downloaded	Primary/Secondary Central Station	EventCode Description	Active/Value	Restoral
Value Configured	Primary Central Station	Pull Station	00	00
Value Uploaded/Downloaded	Primary Central Station	Pull Station	0115	
Value Configured	Primary Central Station	User Defined Monitor 1	00	00
Value Uploaded/Downloaded	Primary Central Station	User Defined Monitor 1	0115	
Value Configured	Primary Central Station	Waterflow	00	00
Value Uploaded/Downloaded	Primary Central Station	Waterflow	0113	
Value Configured	Primary Central Station	User Defined Monitor 2	00	00
Value Uploaded/Downloaded	Primary Central Station	User Defined Monitor 2	0113	
Value Configured	Primary Central Station	Smoke (Photo)	00	00
Value Uploaded/Downloaded	Primary Central Station	Smoke (Photo)	0111	
Value Configured	Primary Central Station	User Defined Detector 1	00	00
Value Uploaded/Downloaded	Primary Central Station	User Defined Detector 1	0111	
Value Configured	Primary Central Station	Smoke (Ion)	00	00
Value Uploaded/Downloaded	Primary Central Station	Smoke (Ion)	0111	
Value Configured	Primary Central Station	User Defined Detector 2	00	00
Value Uploaded/Downloaded	Primary Central Station	User Defined Detector 2	0111	
Value Configured	Primary Central Station	Heat Detect	00	00
Value Uploaded/Downloaded	Primary Central Station	Heat Detect	0114	
Value Configured	Primary Central Station	User Defined Detector 3	00	00
Value Uploaded/Downloaded	Primary Central Station	User Defined Detector 3	0114	
Value Configured	Primary Central Station	Smoke Duct Photo	00	00
Value Uploaded/Downloaded	Primary Central Station	Smoke Duct Photo	0116	
Value Configured	Primary Central Station	User Defined Detector 4	00	00
Value Uploaded/Downloaded	Primary Central Station	User Defined Detector 4	0116	

In the **Event Codes** tab, you can view the information such as values configured to upload or download, details on central station, event codes description, active value, and restoral. Click **Print** to generate a PDF file.

Upload Configuration Data from the FACP

Using the **Upload from Panel** option, you can view the System Status data, History data, Walktest data, Date and Time data from the fire panel. The uploaded information is useful for monitoring the fire alarm system status and identifying troubles, alarms, and other events. When you upload information for the first time, ensure that *all* the information is uploaded from the fire panel.

To upload information from the fire panel, click **Upload/Download > Upload/Download** from the initial customer details window in FS-Tools. The upload/download window opens.

Upload/Download - USB

Customer: Paul Chadbourne
 MAC Address:
 Panel Type: 50 Pt Addr.
 Communication Mode: Direct Connection - USB

Connect Disconnect Connection Settings

Upload from Panel

☐ All Configuration Data ☐ Walktest
☐ System Status ☐ Date and Time
☐ History

View Config File

Upload from Panel View Upload Files

Download to Panel

☐ All Configuration Data ☐ General System Settings
☐ Point Programming ☐ ANN-Bus
☐ Communicator and Event Codes
☐ Zones
☐ Date and Time

Download to Panel ☒ Disable Download Password

Set Secret Code at panel Set Secret Code at PC

PC Panel Communication Status

Zone data uploaded.
 DACT data uploaded.
 ANN Bus data uploaded.
 System programming data uploaded.
 Please wait while uploading point programming data.
 1 of 4 points data packets uploaded for loop 1.
 2 of 4 points data packets uploaded for loop 1.
 3 of 4 points data packets uploaded for loop 1.
 4 of 4 points data packets uploaded for loop 1.
 Point programming for loop 1 devices data uploaded.
 Custom data uploaded.
 Custom adjective noun uploaded.
 Uploaded data saved.

Clear Display

Close

1. Select the **Communication Mode** from the drop-down menu. FS-Tools can connect **directly** with the FACP using a USB cable or **remotely** with an Ethernet connection to the IPOTS-COM communicator.
2. In the **Upload from Panel** section of the window, you can select individual options to upload (System Status, History, Walktest, or Date and Time) or select **all Configuration Data** to upload all information from the fire panel.
3. Click **Upload from Panel**.
4. A message appears to indicate the configuration data is *saved* in FS-Tools. Click **OK**.
5. Click **View Upload Files** to view all the uploaded information from the fire panel such as history data, system status data, and walktest data saved in the FS-Tools database. All the uploaded information is displayed in the **PC Panel Communication Status** window.
6. Click **Close** to close the **Upload/Download** dialog box after the upload/download process is completed.


Connection Settings

The connection settings option displays the details of the USB device, Modem or Serial port attached to the computer for communication with the fire panel. The modem can be a USB modem or a serial modem. For a USB modem, the modem vendor provides the driver that must be installed before launching FS-Tools.


USB Connection Settings

To view the USB device settings:

1. Select the customer for whom the connection settings needs to be viewed.
2. Click **Upload/Download > Connection Settings** in the initial customer screen in FS-Tools. The **Connection Settings** dialog box appears.



3. In **Communication Mode** list, select the *USB* option. The information to view/modify the USB settings appears in the **Connection Settings** dialog box
4. Click **Auto Detect** to detect any USB device attached to the system. The details of the attached USB Device (if any) are displayed in **USB Device Attached to System**.



5. Click **Clear** to clear the displayed data if there are multiple lines of data to scroll through in **USB Device Attached to System**.

6. Click **Close** to close the dialog box after you verify the connection settings between the computer and the fire panel.


Thumb Drive Upload/Download

Transfer Database To Flash Drive


To transfer the panel database *to* a Flash Drive:

1. Insert a Flash Drive into the USB port of your PC.
2. Select the customer for whom the panel settings are to be downloaded to a USB flash drive.
3. Click **Upload/Download > Thumb Drive Upload/Download > Transfer Configuration to Thumb/USB/Flash Drive** in the initial customer screen in FS-Tools.

4. Select the USB port with the Flash Drive from the selection box and click **Save**.




If a Flash Drive is not detected by FS-Tools, you will get a warning message.



FS-Tools will save the program database on the Flash Drive as "FS_50.cfg".

Note: Before loading the new database into the fire panel, the existing database will be saved as file, "FS_50_bak.cfg" on the USB flash drive. Only one new and one saved database can reside on the USB flash drive at a given time.


A confirmation dialog box displays when the database is successfully transferred to the USB drive.




Transfer Database From Flash Drive

To transfer the panel database *from* a flash drive *to* FS-Tools,

1. Insert a Flash Drive into the USB port of your PC.
2. Select the customer from the main screen to where you want to save
3. Click **Upload/Download > Thumb Drive Upload/Download > Transfer Configuration Database From Thumb/USB/Flash Drive** in the initial customer screen in FS-Tools. The USB Selection screen displays.



4. Select the drive with the desired USB stick and click **Read**.
5. Navigate to the configuration file saved to the USB drive from the FACP. The file will have a .bak extension.
6. Select file and click **Open**.
7. The confirmation dialog box displays and the panel configuration is saved to the database.



Configuring Reports


Configuring NFPA Reports

Using FS-Tools, you can configure the NFPA Report Requisites. Configuring the NFPA Reports involves:

- [Configuring the Record of Completion](#)
- [Configuring the Inspection and Testing](#)

To configure the NFPA reports:

1. Using the **Find** option from the initial screen, if necessary, select a customer record. For more information, see [Finding a Customer](#).
2. Click **Configure** to program the fire panel settings. The **Configuration Type** dialog box appears.
3. In the **Select Configuration** box, choose a previously saved configuration which appears in the list.
4. Click **OK**. The **System Info** programming page appears.



5. To open the NFPA report configuration, click **File > NFPA Report Requisite > Record of Completion** or **Inspection and Testing**.

Record of Completion

In FS-Tools, configuring the Record of Completion involves the following steps.

1. Configure the [Protected Site Information](#)
2. Configure the [Fire Alarm System Information](#)
3. Configure the [Type of Fire Alarm System](#)
4. Configure the [System Software](#)
5. Configure the Signaling Line Circuits
 - a. [Manual and Automatic Initiating Device](#)
 - b. [Supervisory Signal- Initiating Devices and Circuits](#)
6. Configure the [Annunciators](#)
7. Configure the [Alarm Notification Devices and Circuits](#)
8. Configure the [System Power Supply](#)
9. Configure the [Record of system installation and System Operation](#)
10. Obtain the [Certifications and Approvals](#)

Protected Site Information

Record Of Completion -> Protected Site Information

Protected Site Information

Site Information

Site Name :

Address :

Description of Property :

Occupancy Type :

Property Representative

Name of property Representative :

Address :

Phone : Fax :

Email :

Authority Having Jurisdiction Over This Property

Name :

Address :

Phone : Fax :

Email :

Next >>

To configure the Protected Site Information:

1. Under **Site Information**, type the **Site Name**, **Address**, **Description of Property** and **Occupancy Type** of the site.
2. Under **Property Representative**, type the **Name of the Property Representative**, **Address**, **Phone**, **FAX** and **E-mail** of the site representative.
3. Under **Authority having jurisdiction over this property**, type the **Name**, **Address**, **Phone**, **FAX** and **E-mail** of the AHJ.

Click **Save to Database** to save the Record of Completion report requisites to database.

Click **Next** or click **Fire Alarm System Information** in the left pane, to view the **Fire Alarm System Information** configuration pane.

Fire Alarm System Information

The fire alarm system information provides information about Installation, Service and Testing.

Record Of Completion -> Fire Alarm System Information

Fire Alarm System Installation, Service and Testing Information

Installation Contractor For This Equipment

Name :

Address :

Phone : Fax :

Email :

Service Organization For This Equipment

Name :

Address :

Phone : Fax :

Email :

Location of as-built drawings :

Location of Historical Test Reports :

Location of system operation and maintenance manuals :

A contract for test and inspection in accordance with NFPA standards is in effect as of : , ,

Contracted Testing Company

Name :

Address :

Phone : Fax :

Email :

Contract Expires : , , Contract Number :

Frequency of routine inspections :

To configure the Fire Alarm System Information:

1. Type the **Name, Address, Phone, FAX** and **E-mail** of the contractor under **Installation Contractor For This Equipment**.
2. Type the **Name, Address, Phone, FAX, E-mail, Location of as-built drawings, Location of Historical Test Reports** and **Location of system operation and maintenance manuals** of the service organization, under **Service Organization of this equipment**.
3. Select the effective date for a contract of test and inspection in accordance with NFPA standards from the drop-down box.
4. Type the **Name, Address, Phone, FAX, E-mail, Contact Number** and **Frequency of routine inspections** of the testing company under **Contracted Testing Company**.
5. Select the **Contract Expires** date from the drop-down box.

Click **Next** or click **Type of Fire Alarm System** in the left pane, to configure the type of fire alarm system.

Click **Prev** to go back to the **Protected Site Information**.

Type of Fire Alarm System or Service

This pane allows you to enter information about the Fire Alarm system type and the details of the organization that is receiving alarm signals, means of transmission and the type of connection.

To configure the Type of Fire Alarm System:

1. Type the **System Type** of the fire alarm system.
2. Enter the name of the organization receiving **Alarm** signal along with the phone details.
3. Enter the name of the organization receiving **Supervisory** signal along with the phone details.
4. Enter the name of the organization receiving **Trouble** signal along with the phone details.
5. Type the name of the **Entity to which alarms are retransmitted** along with the **Phone** details.

Note: The Phone fields allow numbers 0 to 9 and capital letters from A to E only.


6. Type the name of the **Method of retransmission of alarms to that organization or location**.
7. Select the required check box under **Means of transmission from the protected premises to the central station**.
8. Select the required check box under **Type of connection**.

Click **Next** or click **System Software** in the left pane, to configure the System Software.

Click **Prev** to go back to Fire Alarm System Information.

System Software

This pane allows you to configure the Operating system revision level and date.



The image shows a software configuration window titled "Record Of Completion -> System Software". The window has a light gray background and a darker gray header. Below the header, there is a section labeled "System Software". Under this section, there are three main input areas: 1. "Operating system (executive) software revision level :" followed by a text input field. 2. "Site-specific software revision date :" followed by a date picker showing "Friday", "April", and "25, 2014" with a small calendar icon. 3. "Revision completed by :" followed by a text input field. At the bottom right of the window, there are two buttons: "<< Prev" and "Next >>".

To configure the System Software:

1. Type the **Operating System (executive) software revision level** of the alarm software.
2. Select the **Site-specific software revision date**.
3. Type the name of the person in **Revision completed by**.

Click **Next** or click **Signaling Line Circuits** in the left pane, to configure the Signaling Line Circuit.

Click **Prev** to go back to **Type of Fire Alarm System**.

Signaling Line Circuit

Manual and Automatic Initiating Devices and Circuits

In this pane you can configure the Alarm Initiating Devices and Circuits, Manual Initiating Devices and Automatic Initiating Devices. It also allows you to configure the Supervisory Signal –Initiating Devices and Circuits.

Record Of Completion -> Signaling Line Circuits -> Manual and Automatic Initiating Devices and Circuits

Signaling Line Circuit

Loop 1 : Quantity : Style : **Style 4** Class :

Alarm-Initiating Devices and Circuits

Loop 1 : Quantity : Style : **Style 4** Class :

Manual Initiating Devices - Manual Pull Stations

Number of Manual Pull Stations :

Type of devices

☐ Addressable ☐ Conventional ☐ Coded ☐ Transmitter ☐ N/A

Automatic Initiating Devices - Duct Smoke Detectors

Number of Duct Smoke Detectors :

Type of coverage :

Type of devices

☐ Addressable ☐ Conventional ☐ Coded ☐ Transmitter ☐ N/A

Type of smoke detector sensing technology

☐ Ionization ☐ Photoelectric

Automatic Initiating Devices - Heat Detectors

Number of Heat Detectors :

Type of coverage

☐ Complete Area ☐ Partial Area ☐ Nonrequired partial Area ☐ N/A

Type of devices

☐ Addressable ☐ Conventional ☐ Coded ☐ Transmitter ☐ N/A

Automatic Initiating Devices - Sprinkler Waterflow Detectors

Number of Waterflow Detectors :

Type of devices

☐ Addressable ☐ Conventional ☐ Coded ☐ Transmitter ☐ N/A

Automatic Initiating Devices - Area Smoke Detectors

Number of Area Smoke Detectors :

Type of coverage

☐ Complete Area ☐ Partial Area ☐ Nonrequired partial Area ☐ N/A

Type of devices

☐ Addressable ☐ Conventional ☐ Coded ☐ Transmitter ☐ N/A

Type of smoke detector sensing technology

☐ Ionization ☐ Photoelectric

Automatic Initiating Devices - Alarm Verification

Number of devices subject :

To configure the Signaling Line Circuits:

1. Enter the total number of devices installed on the SLC in the **Quantity** box.
2. Select the wiring **Style** from the drop-down box.
3. Enter the wiring **Class** (Class A or Class B).
4. In **Alarm Initiating devices and circuits**, repeat the steps 1 through 3 of Signaling Line Circuits to fill the data.

Note: The number of detectors and input modules here depends on the number of devices mapped in the FACP. The maximum number of devices is 50 total.

5. Under **Manual Initiating Devices –Manual Pull Stations**, type the **Number of manual pull stations** added to the FACP configuration and click the required **Type of devices** check box.
6. Under **Automatic Initiating Devices – Duct Smoke Detectors**, type the **Number of Duct Smoke Detectors** added in FACP configuration and **Type of Coverage**.
7. Select the required **Type of devices** and **Type of smoke detector sensing technology** check boxes.
8. Under **Automatic Initiating Devices – Heat Detectors**, type the **Number of Heat Detectors** added in FACP configuration and select the required checkboxes for **Type of Coverage** and **Type of Devices**.
9. Under **Automatic Initiating Devices – Sprinkler Waterflow Detectors**, type the **Number of Waterflow Detectors** added in FACP configuration and click the required checkboxes for Type of devices.
10. Under **Automatic Initiating Devices – Area Smoke Detectors**, type the **Number of area Smoke Detectors** added in FACP configuration and click the required checkboxes for **Type of Coverage**, **Type of Devices** and **Type of smoke detector sensing technology**.
11. Under **Automatic Initiating Devices – Alarm Verification**, type the **Number of devices subject to alarm verification**.
12. Click **Enabled** if alarm verification on this system is enabled and type the number of seconds in the **Set for**.

Note: This radio button is enabled if *all* the detectors on this system are in alarm verification otherwise it is disabled.

Click **Next** or click **Supervisory Signal** in the left pane to configure the Supervisory Signal- Initiating Devices and Circuits.

Click **Prev** to go back to **System Software**.

Supervisory Signal

The Supervisory Signal pane allows you to configure the Initiating Devices and Circuits namely Fire pump, Sprinkler System, and Engine Driven Generators.

Record Of Completion -> Signaling Line Circuit -> Supervisory Signal-Initiating Devices and Circuits

Supervisory Signal-Initiating Devices and Circuits - Fire Pump

Type of fire pump

☒ Electric ☐ Diesel

Type of fire pump supervisory devices

☐ Addressable ☐ Conventional ☐ Coded ☐ Transmitter ☐ N/A

Fire Pump Functions Supervised

☐ Fire pump power ☐ Fire pump running ☐ Fire pump phase reversal

☐ Selector switch not in auto ☐ Engine or control panel trouble ☐ Low fuel

Other :

Supervisory Signal-Initiating Devices and Circuits - Sprinkler System

Number of valve supervisory switches :

Type of devices

☐ Addressable ☐ Conventional ☐ Coded ☐ Transmitter ☐ N/A

Supervisory Signal-Initiating Devices and Circuits - Engine-Driven Generator

Type of generator supervisory devices

☐ Addressable ☐ Conventional ☐ Coded ☐ Transmitter ☐ Low Fuel

☐ Engine or control panel trouble ☐ Generator running ☐ Selector switch not in auto ☐ N/A

Other :

To configure the Supervisory Signal:

1. Under **Supervisory Signal – Initiating Devices and Circuits – Fire Pump**, select the required check box for **Type of fire pump**.
2. Click the required check box for **Type of fire pump supervisory devices**.
3. Click the required check box for **Fire Pump Functions Supervised**.
4. Type the **Other** supervisory signals information in the box provided.
5. Under **Supervisory Signal – Initiating Devices and Circuits – Sprinkler System**, type the **Number of valve supervisory switches**.
6. Click the required check box for **Type of devices**.
7. Under **Supervisory Signal – Initiating Devices and Circuits – Engine-Driven Generator**, click the required check boxes for **Type of generator supervisory devices**.
8. Type the **Other** supervisory signals information in the box provided.

Click **Next** or click **Annunciators** in the left pane to configure the annunciators.

Click **Prev** to go back to **Signaling Line Circuit**.

Annunciators

The **Annunciators** pane allows you to configure the Local/Remote, Type and Location for the Annunciators.

Record of Completion -> Annunciators

Annunciators

Description	Local/Remote	Type	Location
Primary ANN Bus Address 1		Not Installed	
Primary ANN Bus Address 2		Not Installed	
Primary ANN Bus Address 3		Not Installed	
Primary ANN Bus Address 4		Not Installed	
Primary ANN Bus Address 5		Not Installed	
Primary ANN Bus Address 6		Not Installed	
Primary ANN Bus Address 7		Not Installed	
Primary ANN Bus Address 8		Not Installed	
Secondary ANN Bus Address...		Not Installed	
Secondary ANN Bus Address...		Not Installed	
Secondary ANN Bus Address...		Not Installed	
Secondary ANN Bus Address...		Not Installed	
Secondary ANN Bus Address...		Not Installed	
Secondary ANN Bus Address...		Not Installed	
Secondary ANN Bus Address...		Not Installed	
Secondary ANN Bus Address...		Not Installed	

<< Prev Next >>

To configure the Annunciators:

1. Under **Local/Remote** select *local* or *remote* for each Annunciator address.
2. Select the required type (*Addressable*, *Directory*, *Graphic*, *N/A*, *Not Installed*, *ANN-80*, *ANN-I/O*, *ANN-S/PG*, *ANN-(R)LED*, *ANN-RLY*, or *ANN-100*) for each Annunciator address.
3. Type the **Location** of each annunciator.

Click **Next** or click **Alarm Notification Devices** in the left pane, to configure the alarm notification devices and circuits.

Click **Prev** to go back to **Supervisory Signal**.

Alarm Notification Devices and Circuits

The Alarm Notification devices and circuits pane allows you to configure the parameters namely Emergency Voice Alarm Service, Telephone jacks, Types and Quantities of Non-voice Notification Appliances Installed and Non-voice Audible System.

Record Of Completion -> Alarm Notification Devices and Circuits

Alarm Notification Devices and Circuits - Emergency Voice Alarm Service

Number of single voice alarm channels :

Number of multiple voice alarm channels :

Number of speakers :

Number of speaker zones :

Alarm Notification Devices and Circuits - Telephone Jacks

Number of telephone jacks installed :

Number of telephone handsets stored on site :

Type of telephone system installed

☐ Electrically powered ☐ Sound powered ☐ N/A

Alarm Notification Devices and Circuits - Nonvoice Audible System

Loop 1 : Quantity : Style : Class :

NAC : Quantity : Style : Class :

Alarm Notification Devices and Circuits - Types and Quantities of Nonvoice Notification Appliances Installed

	SLC	NAC	
Bells :	<input type="text"/>	<input type="text"/>	With visual device : <input type="text"/>
Horns :	<input type="text"/>	<input type="text"/>	With visual device : <input type="text"/>
Chimes :	<input type="text"/>	<input type="text"/>	With visual device : <input type="text"/>
Visual devices without audible devices :	<input type="text"/>	<input type="text"/>	Other (describe) : <input type="text"/>

Emergency Control Functions Activated

☐ Hold-open door releasing devices ☐ Smoke management or smoke control ☐ Door unlocking

☐ Elevator recall ☐ Other :

To configure the Alarm Notification Devices and Circuits:

1. Under **Emergency Voice Alarm Service**, enter the **Number of single** and **multiple voice alarm channels**.
2. Enter the **Number of Speakers** and **Number of Speaker Zones**.
3. Under **Telephone jacks**, enter the **Number of telephone jacks installed**.
4. Enter the **Number of telephone handsets store on site**.
5. Click the required check box in **Type of telephone system installed**.
6. Under the **Non-Voice Audible System option**, enter the **Quantity** for the **SLC Loop 1** and **NAC**.
7. Select the required **Style** for the **NAC** .
8. Type the **Class** for **NAC** .
9. Enter the number of **Bells** required under **NAC, With visual devices** in the boxes provided.

Note: Under **Types and Quantities of Non-voice Notification Appliances Installed**, the number of Bell devices displayed is based on the number of Bell devices added in **Output modules** of the fire panel configuration.

10. Enter the number of **Horns** required under **NAC, With visual devices** in the boxes provided

Note: The number of **Horn devices** displayed is based on the number of Horn devices added in **Output modules** of the fire panel configuration.

11. Enter the number of **Chimes** required under **NAC, With visual devices** in the boxes provided.
12. Enter the number of **Visual devices without audible** devices under **NAC**, in the boxes provided.
13. Under the **Emergency Control Functions Activated** option, select the required options by clicking the checkboxes.

Click **Next** or click **System Power Supply** in the left pane, to configure the alarm notification devices and circuits.

click **Prev** to go back to **Annunciators**.

System Power Supply

The system power supply pane allows you to configure the primary and the secondary power supply for the system.

Record Of Completion -> System Power Supply

System Power Supply - Primary Power

Nominal voltage : Amps :

Overcurrent protection : Type Amps :

Location (of primary supply panelboard) :

Disconnecting means location :

System Power Supply - Secondary Power

Location : Type :

Nominal voltage : Current rating :

Number of standby batteries : Amp hour rating :

Location of emergency generator :

Location of fuel storage :

Calculated capacity of secondary power to drive the system

In standby mode : In alarm mode :

<< Prev Next >>

To configure the system power supply:

1. Enter the **Nominal voltage** value and **Amps** under primary power.
2. Enter the **Overcurrent protection Type** and **Amps**.
3. Enter the **Location of primary supply panel board for primary power**.
4. Enter the **Disconnecting means location of primary power**.
5. Under **Secondary power**, Enter the **Location** and **Type** of power supply.
6. Enter the **Nominal voltage value** and **Current rating** for the secondary power.
7. Enter the **Number of standby batteries** and Amp hour rating.
8. Enter the **location of emergency generator & location of fuel storage** for secondary power.
9. Under **Calculated capacity of secondary power to drive the system**, Enter the calculated capacity of secondary power in standby mode and in alarm mode.

Click **Next** or click **Record of System Installation and System Operation** in the left pane to configure the alarm notification devices and circuits.

click **Prev** to go back to **Alarm Notification Devices and Circuits**.

Record of System Installation and System Operation

This pane allows you to fill the attributes to ensure that the system installation and system operation is in accordance with the NFPA standards.

Record Of Completion -> Record of System Installation and System Operation

Record of System Installation

Fill out after all installation is complete and wiring has been checked for opens, shorts, ground faults, and improper branching, but before conducting operational acceptance tests.
The system has been installed in accordance with the following NFPA standards: (Note any or all that apply.)

☐ NFPA 72® ☐ NFPA 70®, Article 760 ☐ Manufacturer's published instructions ☐ Other (please specify) : _____

_____ Edition

System deviations from referenced NFPA standards : _____

Signed : _____ Printed name : _____

Organization : _____ Title : _____

Date : Friday , April 25, 2014 Phone : _____

Record of System Operation

All operational features and functions of this system were tested by or in the presence of the signer shown below, on the date shown below, and were found to be operating properly in accordance with the requirements of :

☐ NFPA 72® ☐ NFPA 70®, Article 760 ☐ Manufacturer's published instructions ☐ Other (please specify) : _____

_____ Edition

☐ Documentation in accordance with Inspection and Testing Form is attached, following NFPA 72® standards

Signed : _____ Printed name : _____

Organization : _____ Title : _____

Date : Friday , April 25, 2014 Phone : _____

<< Prev Next >>

To configure the Record of system installation and system operation:

1. Under **Record of System Installation**, select the required checkboxes to ensure that the system is installed in accordance with the standards and enter the corresponding NFPA **Edition**.
2. Enter the **System deviations from referenced NFPA standards**.
3. Enter the **Printed name, Organization, Title, Date** and **Phone** details of the person verifying the system installation.
4. Under **Record of System Operation**, select the required checkboxes to ensure that the system operation is in accordance with the standards and enter the corresponding NFPA **Edition**.
5. Enter the **Printed name, Organization, Title, Date** and **Phone** details of the person monitoring the system operation.

Click **Next** or click **Certifications and Approvals** in the left pane to certify and approve the **Record of completion**.

Click **Prev** to go back to **System Power Supply**.

Certifications and Approvals

This pane allows you to get the certification and approvals from the following personnel, specifying that the system is installed and tested according to the NFPA standards.

- System installation contractor
- System service contractor
- Central Station
- Property Representative
- Authority Having Jurisdiction

Record Of Completion -> Certifications and Approvals

Certifications and Approvals - System Installation Contractor
This system as specified herein has been installed and tested according to all NFPA standards cited herein
Signed : Printed name :
Organization : Title :
Date : Friday , April 25, 2014 Phone :

Certifications and Approvals - System Service Contractor
This system as specified herein has been installed and tested according to all NFPA standards cited herein
Signed : Printed name :
Organization : Title :
Date : Friday , April 25, 2014 Phone :

Certifications and Approvals - Central Station
This system as specified herein will be monitored according to all NFPA standards cited herein
Signed : Printed name :
Organization : Title :
Date : Friday , April 25, 2014 Phone :

Certifications and Approvals - Property Representative
This system as specified herein has been installed and tested according to all NFPA standards cited herein
Signed : Printed name :
Organization : Title :
Date : Friday , April 25, 2014 Phone :

Certifications and Approvals - Authority Having Jurisdiction
I have witnessed a satisfactory acceptance test of this system and find it to be installed and operating properly in accordance with its approved plans and specifications, its approved sequence of operations and with all NFPA standards cited herein
Signed : Printed name :
Organization : Title :
Date : Friday , April 25, 2014 Phone :

<< Prev

obtain the Certification and Approvals:

1. Type the **Printed name, Organization, Title, Date** and **Phone** details from the **System Installation Contractor**.
2. Similarly fill in the details for **System Service Contractor, Central Station, Property Representative and Authority Having Jurisdiction**.

Click Prev to go back to **Record of System Installation and System Operation**.

To configure the **Inspection and Testing** click **File > NFPA Report Requisite > Inspection and Testing**.

Configuring Inspection and Testing

In FS-Tools, configuring the Inspection and Testing involves the following steps.

1. Configuring [General Information](#)
2. Configuring [Type Transmission](#)
3. Configuring the Signaling Line Circuits
 - a. [Alarm Initiating Devices](#)
 - b. [Alarm Notification Appliances](#)
 - c. [Supervisory Signal-Initiating Devices](#)
4. Configuring [System Power supplies](#)
5. Configuring [Notifications Prior to Testing](#)
6. Configuring [System Tests and Inspections](#)
7. Configuring [Secondary Power](#)
8. Configuring [Combination Systems](#)
9. Configuring [Emergency Communication Equipment](#)
10. Configuring [Supervising Station Monitoring](#)
11. Obtaining [Notifications and Approvals](#)

General Information

The General Information pane allows you to enter the information about Service Organization, Monitoring Entity, Approving Agency, Service and Property details.

Inspection and Testing -> General Information

Date : Monday , April 28, 2014 Time : 09:17

Service Organization

Name :

Address :

Representative :

License No. :

Telephone :

Monitoring Entity

Contact :

Telephone :

Monitoring Account Ref. No. :

Approving Agency

Contact :

Telephone :

Service

☐ Weekly ☐ Monthly ☐ Quarterly ☐ Semiannually

☐ Annually ☐ Other (Specify) :

Property Name (User)

Name :

Address :

Owner Contact :

Telephone :

Next >>

To configure the General Information:

Select the **Date** and **Time** for general information from the drop-down menus.

1. Enter the **Name, Address, Representative, License Number** and **Telephone Number of the Service Organization**.
2. Enter the **Contact, Telephone**, and **Monitoring Account Ref Number** of the **Monitoring Entity**.
3. Enter the **Contact** and **Telephone Number** of the **Approving Agency**.
4. Select the required maintenance schedule from the **Service** checkbox.
5. Enter the **Name, Address, Owner Contact**, and **Telephone number** of the **Property Name (User)**.

Click **Next** or click **Type Transmission** node in the left pane to configure the transmission type.

Type Transmission

The Type Transmission pane allows you to enter the details about the type of transmission, control unit, Model Number, Software revisions, date of service and configuration revision.

Inspection and Testing -> Type Transmission

Type Transmission

☐ McCulloh ☐ Multiplex ☐ Digital ☐ Reverse Priority

☐ RF ☐ Other (Specify) :

Control Unit

Manufacturer :

Model No. : Circuit Styles :

Number of Circuits : Software Rev. :

Last Date System Had Any Service Performed : Monday , April 28, 2014

Last Date That Any Software or Configuration Was Revised : Monday , April 28, 2014

<< Prev Next >>

To configure the Type Transmission:

1. Select the required check box for Transmission Type.
2. Enter the **Control Unit of the Manufacturer, Model No, Circuit Style, Number of Circuits** and **Software Rev** of the transmission.
3. Select the date of **Last Date of System service** and **Last date of Software or Configuration revision** from the drop-down menus.

Click **Next** or click **Signaling Line Circuits** in the left pane to configure the signaling line circuits.

Click **Prev** to go back to **General Information**.

Signaling Line Circuit

Alarm Initiating Devices and Circuit Information

The Alarm Initiating Devices and Circuits pane allows you to enter the information about the quantity of devices installed, Circuit style and Quantity of devices tested.

Inspection and Testing -> Signaling Line Circuit -> Alarm-Initiating Devices and Circuit Information

Signaling Line Circuits

Loop 1 : Quantity : Style : Style 4

Alarm-Initiating Devices and Circuit Information

	Quantity of Devices Installed	Circuit Style	Quantity of Devices Tested
Manual Fire Alarm Boxes		Style 4	
Ion Detectors		Style 4	
Photo Detectors		Style 4	
Duct Detectors		Style 4	
Heat Detectors		Style 4	
MultiCriteria Detectors		Style 4	
Waterflow Switches		Style 4	
Supervisory Switches		Style 4	
Other (Specify) :		Style 4	

Alarm verification feature

☐ Enabled ☒ Disabled

<< Prev Next >>

To configure the Alarm-Initiating Devices and Circuit Information:

1. Under Signaling Line circuits, enter the number of devices configured in fire panel configuration in **Quantity** for **Loop1**.
2. Select the **Style** configured in FACP programming for **Loop1**.
3. Under **Alarm Initiating Devices and Circuit Information**, enter the **Quantity of Devices Installed** in panel configuration for each of the following:
 - Manual Fire Alarm boxes
 - Ion Detectors
 - Photo Detectors
 - Duct Detectors
 - Heat Detectors
 - Water flow switches
 - Supervisory switches
 - Other (Specify)
4. Select the corresponding **Circuit Style** for the devices installed
5. Enter the corresponding **Quantity of Devices Tested** from the devices installed.
6. Click **Enable** to enable the **Alarm Verification feature**.

Note: When all the detectors are in alarm verification state, the radio button is enabled. By default, the button is disabled.

Click **Next** or click **Alarm Notification Appliances** in the left pane to configure the alarm notification appliances and circuit information.

Click **Prev** to go back to **Type Transmission**.

Alarm Notification Appliances

The alarm notification appliances pane allows you to configure the quantity of appliances installed, tested, and circuit style.

To configure the Alarm Notification Appliances and circuit information:

1. Under **Alarm Notification Appliances and Circuit Information**, enter the **Quantity of Appliances Installed** (configured in FACP programming under **SLC** and **NAC** for the following:

- Bells
- Horns
- Chimes
- Strobes
- Speakers
- Other (Specify)

2. Select the corresponding **Circuit Style** for the Appliances installed.

3. Enter the corresponding **Quantity of Appliances Tested** from the Appliances installed.

4. Click **Yes** to confirm the circuits monitored for integrity.

Click **Next** or click **Supervisory Signal - Initiating Devices** in the left pane, to configure the Supervisory Signal - Initiating Devices and Circuit Information.

Click **Prev** to go back to **Signaling Line Circuits -Alarm Initiating Devices and Circuits**.

Supervisory Signal - Initiating Devices and Circuit Information

The Supervisory Signal - Initiating Devices pane allows you to enter the information about the quantity of devices installed, Circuit style and Quantity of devices tested.

Inspection and Testing -> Signaling Line Circuit -> Supervisory Signal - Initiating Devices and Circuit Information

Supervisory Signal - Initiating Devices and Circuit Information

	Quantity of Devices Installed	Circuit Style	Quantity of Devices Tested
Building Temp.	<input type="text"/>	Style 4	<input type="text"/>
Site Water Temp.	<input type="text"/>	Style 4	<input type="text"/>
Site Water Level	<input type="text"/>	Style 4	<input type="text"/>
Fire Pump Power	<input type="text"/>	Style 4	<input type="text"/>
Fire Pump Running	<input type="text"/>	Style 4	<input type="text"/>
Fire Pump Auto Position	<input type="text"/>	Style 4	<input type="text"/>
Fire Pump or Pump Controller Trouble	<input type="text"/>	Style 4	<input type="text"/>
Fire Pump Running	<input type="text"/>	Style 4	<input type="text"/>
Generator in Auto Position	<input type="text"/>	Style 4	<input type="text"/>
Generator or Controller Trouble	<input type="text"/>	Style 4	<input type="text"/>
Switch Transfer	<input type="text"/>	Style 4	<input type="text"/>
Generator Engine Running	<input type="text"/>	Style 4	<input type="text"/>
Other (Specify) :	<input type="text"/>	Style 4	<input type="text"/>

<< Prev

Next >>

To configure the Supervisory Signal - Initiating Devices and Circuit Information:

1. Under Supervisory Signal - Initiating Devices and Circuit Information, enter the **Quantity of Devices Installed** for the following:

- Building Temp
- Site Water Temp
- Site Water Level
- Fire Pump Power
- Fire Pump Running
- Fire Pump Auto Position
- Fire Pump or Pump Controller Trouble
- Generator in Auto Position
- Generator or Controller Trouble
- Switch Transfer
- Generator Engine Running
- Other (Specify)

2. Select the corresponding **Circuit Style** for the devices installed.

3. Enter the corresponding **Quantity of Devices Tested** from the devices installed.

Click **Next** or click **System Power Supplies** in the left pane to configure the System Power Supply.

Click **Prev** to go back to **Alarm Notification Appliances**.

System Power Supplies

The system power supplies pane allows you to configure the primary power, secondary power, and the standby system.

Inspection and Testing -> System Power Supplies

System Power Supply - Primary Power

Nominal voltage : Amps :
Overcurrent protection : Type Amps :
Location (of primary supply panelboard) :
Disconnecting means location :

System Power Supply - Secondary Power

Description : Storage Battery : Amp-Hr Rating
Calculated capacity in Amp-Hrs to operate system for hours
Engine-driven generator dedicated to fire alarm system :
Location of fuel storage :

System Power Supply - Emergency or Standby System

Emergency or standby system used as a backup to primary power supply, instead of using a secondary power supply

Legally required standby described in NFPA 70®, Article 701
Optional standby system described in NFPA 70®, Article 702, which also meets the performance requirements of Article 700 or 701
Emergency system described in NFPA 70®, Article 700

Type Battery

☐ Dry Cell ☐ Lead-Acid ☐ Nickel-Cadmium
☐ Sealed Lead Acid ☐ Other (Specify) :

<< Prev Next >>

configure the system power supply:

1. Enter the **Nominal voltage value** and **Amps** for the primary power source.
2. Enter the **Overcurrent protection Type** and **Amps** for the primary power source.
3. Enter the **Location of primary supply panel board** for the primary power source.
4. Enter the **Disconnecting means location** for the primary power source.
5. Under Secondary power, enter the name of the **Storage Battery** and its **Amp Hr Rating** for the secondary power source.
6. Enter the **Calculated capacity** and **Amp Hrs** needed to operate the system for the secondary power source.
7. Enter the name of the **Engine driven generator dedicated to fire alarm system** and its **Amp hour rating**.
8. Enter the **Location of fuel storage**.
9. Under **Emergency or Standby System**, enter the name of the **legally required standby system described in NFPA 70, Article 701**.
10. Enter the **Optional standby system described in NFPA 70, Article 702**.
11. Enter the name of the **Emergency system described in NFPA 70, Article 700**.
12. Select the required check box under **Battery type**.

Click **Next** or click **Notifications Prior to any Testing** in the left pane to configure the Notifications.

Click **Prev** to go back to **Supervisory Signal - Initiating Devices and Circuit Information**.

Notifications Prior to Testing

The Notifications Prior to any testing pane allows you to set the notifications and time on monitoring entities, building occupants, and building Management.

Prior to any testing	Notifications are made	Who	Time
Monitoring Entity	<input type="radio"/> Yes <input type="radio"/> No		12:03
Building Occupants	<input type="radio"/> Yes <input type="radio"/> No		12:03
Building Management	<input type="radio"/> Yes <input type="radio"/> No		12:03
Other (Specify)	<input type="radio"/> Yes <input type="radio"/> No		12:03
AHJ Notified of Any Impairments	<input type="radio"/> Yes <input type="radio"/> No		12:03

To configure the Notifications:

1. Click the specific option to confirm the **Notifications are made** by monitoring Entity.
2. In the **Who** text box type the name of the person through whom the notifications are made.
3. Select the **Time** at which the notifications are made.
4. Repeat steps 1 through 3 for **Building Occupants, Building Management, Others** and **AHJ Notified of Any Impairments**.

Click **Next** or click **System Tests and Inspections** in the left pane to configure the system tests and inspections.

Click **Prev** to go back to **System Power Supplies**.

System Tests and Inspections

The system tests and inspection pane allows you to configure the test and inspections type for control units, interface equipment, lamps/LEDs, fuses, power supply, trouble signals, disconnect switches, and ground fault monitoring.

Type	Visual	Functional	Comments
Control Unit	<input type="checkbox"/>	<input type="checkbox"/>	
Interface Equipment	<input type="checkbox"/>	<input type="checkbox"/>	
Lamps/LEDs	<input type="checkbox"/>	<input type="checkbox"/>	
Fuses	<input type="checkbox"/>	<input type="checkbox"/>	
Primary Power Supply	<input type="checkbox"/>	<input type="checkbox"/>	
Trouble Signals	<input type="checkbox"/>	<input type="checkbox"/>	
Disconnect Switches	<input type="checkbox"/>	<input type="checkbox"/>	
Ground-Fault Monitoring	<input type="checkbox"/>	<input type="checkbox"/>	

To configure the System Tests and Inspections:

Select the **Visual** or **Functional** checkbox for the following, and type any suitable comments:

- Control Unit
- Interface Equipment
- Lamps/LEDs
- Fuses
- Primary Power Supply
- Trouble Signals
- Disconnect Switches
- Ground Fault Monitoring

Click **Next** or click **Secondary Power** in the left pane to configure the secondary power type.

Click **Prev** to go back to **Notifications Prior to any Testing**.

Secondary Power

The secondary power pane allows you configure the type of secondary power and notification appliances for panels.

Type	Comments
Battery Condition <input type="checkbox"/> Visual	
Load Voltage <input type="checkbox"/> Functional	
Discharge Test <input type="checkbox"/> Functional	
Charger Test <input type="checkbox"/> Functional	
Specific Gravity <input type="checkbox"/> Functional	
TRANSIENT SUPPRESSORS <input type="checkbox"/> Visual	
REMOTE ANNUNCIATORS <input type="checkbox"/> Visual <input type="checkbox"/> Functional	
NOTIFICATION APPLIANCES	
Audible <input type="checkbox"/> Visual <input type="checkbox"/> Functional	
Visible <input type="checkbox"/> Visual <input type="checkbox"/> Functional	
Speakers <input type="checkbox"/> Visual <input type="checkbox"/> Functional	
Voice Clarity <input type="checkbox"/> Functional	

To configure the Secondary power:

1. Under **Type**, select the **Visual** checkbox and type any comments for **Battery Condition**.
2. Select the **Functional** checkbox and type any comment for **Load Voltage**, **Discharge Test**, **Charger Test**, and **Specific Gravity**.
3. Select the **Visual** checkbox and type any comment for **Transient Suppressors**.
4. Select the required checkbox for **Remote Annunciators** and type any comment.
5. Under **Notification Appliances**, select the required checkbox and type any comments for the **Audible**, **Visible** and **Speakers** appliances.
6. Select the **Functional** checkbox and type any comment for **Voice Clarity**.

Click **Next** or click **Combination Systems** in the left pane, to configure the combination systems.

Click **Prev** to go back to **System Tests and Inspections**.

Combination Systems

The Combination Systems pane allows you to enter the information about different Devices/System and equipment.

Inspection and Testing -> Combination Systems

Combination Systems

Fire Extinguisher Monitoring Device/System ☐ Visual ☐ Device Operation ☐ Simulated Operation

Carbon Monoxide Detector/System ☐ Visual ☐ Device Operation ☐ Simulated Operation

(Specify) ☐ Visual ☐ Device Operation ☐ Simulated Operation

Interface Equipment

(Specify) ☐ Visual ☐ Device Operation ☐ Simulated Operation

(Specify) ☐ Visual ☐ Device Operation ☐ Simulated Operation

(Specify) ☐ Visual ☐ Device Operation ☐ Simulated Operation

Special Hazard Systems

(Specify) ☐ Visual ☐ Device Operation ☐ Simulated Operation

(Specify) ☐ Visual ☐ Device Operation ☐ Simulated Operation

(Specify) ☐ Visual ☐ Device Operation ☐ Simulated Operation

Special Procedure :

<< Prev Next >>

To configure the Combination Systems:

1. Select the required checkboxes for **Fire Extinguisher Device/System** and **Carbon Monoxide Detector/System**.
2. Specify other **Device/System** and select the appropriate checkboxes.
3. Under **Interface Equipment**, specify/type the equipment and click the required checkboxes.
4. Under **Special Hazard Systems**, specify/type the **Systems** and click the required checkboxes.
5. Enter the description of the **Special Procedure**.

Click **Next** or click **Emergency Communication Equipment** in the left pane to configure the Emergency Communication Equipment.

Click **Prev** to go back to **Secondary Power**.

Emergency Communication Equipment

The Emergency Communication Equipment pane allows you to configure the communication equipment.

Emergency Communications Equipment		Comments
Phone Set	<input type="checkbox"/> Visual <input type="checkbox"/> Functional	
Phone Jacks	<input type="checkbox"/> Visual <input type="checkbox"/> Functional	
Off-Hook Indicator	<input type="checkbox"/> Visual <input type="checkbox"/> Functional	
Amplifier(s)	<input type="checkbox"/> Visual <input type="checkbox"/> Functional	
Tone Generator(s)	<input type="checkbox"/> Visual <input type="checkbox"/> Functional	
Call-in Signal	<input type="checkbox"/> Visual <input type="checkbox"/> Functional	
System Performance	<input type="checkbox"/> Visual <input type="checkbox"/> Functional	

To configure the Emergency Communication Equipment:

1. Under **Emergency Communication Equipment** select the appropriate checkbox and type the comments for the following:

- Phone Set
- Phone Jacks
- Off Hook Indicator
- Amplifiers
- Tone Generators
- Call-in signal
- System Performance

Click **Next** or click **Supervising Station Monitoring** in the left pane to set the Notification and get the approvals.

Click **Prev** to go back to **Combination Systems**.

Supervising Station Monitoring

The Supervising Station Monitoring pane allows you to configure the Station Monitoring devices.

The screenshot shows a software window titled "Inspection and Testing -> Supervising Station Monitoring". Inside, there is a section titled "Supervising Station Monitoring" which contains a table-like structure for configuring six different signals. Each row represents a signal type: Alarm Signal, Alarm Restoration, Trouble Signal, Trouble Signal Restoration, Supervisory Signal, and Supervisory Restoration. For each signal, there are two radio buttons labeled "Yes" and "No", a "Time" column with a digital clock display showing "12:03" and up/down arrows, and a "Comments" column with a text input field. At the bottom right of the window, there are two buttons: "<< Prev" and "Next >>".

		Time	Comments
Alarm Signal	<input type="radio"/> Yes <input type="radio"/> No	12:03	
Alarm Restoration	<input type="radio"/> Yes <input type="radio"/> No	12:03	
Trouble Signal	<input type="radio"/> Yes <input type="radio"/> No	12:03	
Trouble Signal Restoration	<input type="radio"/> Yes <input type="radio"/> No	12:03	
Supervisory Signal	<input type="radio"/> Yes <input type="radio"/> No	12:03	
Supervisory Restoration	<input type="radio"/> Yes <input type="radio"/> No	12:03	

To configure the Supervising Station Monitoring:

1. Under **Supervising Station Monitoring**,
 - a. Click the required **Yes/No** options.
 - b. Type or select the required time in the **Time** box.
 - c. Type any comments in the **Comments** text box for the following:
 - Alarm Signal
 - Alarm Restoration
 - Trouble Signal
 - Trouble Signal Restoration
 - Supervisory Signal
 - Supervisory Restoration

Click **Next** or click **Notification and Approvals** in the left pane to set the Notification and get the approvals.

Click **Prev** to go back to **Emergency Communication Equipment**.

Notifications and Approvals

The Notification and Approvals pane allows you to set testing and functional notifications and to get approval in accordance with the applicable NFPA standards.

Inspection and Testing -> Notifications and Approvals

Notification that testing is complete

	Notifications are made	Who	Time
Building Management	<input type="radio"/> Yes <input type="radio"/> No		12:03
Monitoring Agency	<input type="radio"/> Yes <input type="radio"/> No		12:03
Building Occupants	<input type="radio"/> Yes <input type="radio"/> No		12:03
Other (Specify)	<input type="radio"/> Yes <input type="radio"/> No		12:03

Not functioning correctly

The following are not functioning correctly :

System restored to normal operation :

Date :
Monday , April 28, 2014
Time :
12:03

Approvals

This testing was performed in accordance with applicable NFPA standards

Name of Inspector :

Date :
Monday , April 28, 2014
Time :
12:03

Signature :

Name of Owner or Representative :

Date :
Monday , April 28, 2014
Time :
12:03

Signature :

<< Prev
Next >>

To set the Notifications and get the approval:

1. Under **Notification that testing is complete**,
 - a. Confirm whether or not **Notifications are made**.
 - b. Enter the name of the person through whom the notification and testing is completed in the **Who** text box.
 - c. Select the **Time** when the notifications are set for the following:
 - Building Management
 - Monitoring Agency
 - Building Occupants
 - Others
2. Under **Not functioning correctly**, enter the name of devices and system which are not functioning correctly and also enter the name of the system restored to normal operation.
3. Select the **Date** and **Time** to specify when the above testing is done.
4. Under **Approvals**, enter the **Name of the Inspector** who performed the testing in accordance with NFPA standards.
5. Select the **Date** and **Time** and get the **Signature**.
6. Enter the **Name** of the **Owner or Representative**.
7. Select the **Date** and **Time** and get the **Signature**.

Click **Next** or click **Upload Information** in the left pane to upload the **Device Maintenance Information** in FS-Tools.

Click **Prev** to go back to **Emergency Communication Equipment**.

Upload Information


Device Maintenance Information

To upload the information, click **File > NFPA Report Requisite > Inspection and Testing > Upload Information > Device Maintenance Information**. The Device Maintenance Information pane appears.


[illegible]

To upload Device Maintenance information from the fire panel:

1. In the Device Maintenance Information window, click the **Upload Data** button. The **Upload NFPA Requisites** dialog box appears.



2. Click the **Connection Settings** button. The **Connection Settings** dialog appears.




3. Select the required **Communication Mode** from the list. Settings for the selected communication mode are displayed.

4. Enter the required information in the fields and click the **Save and Exit** button. The selected **Communication Mode** is displayed in the corresponding field.

5. Click the **Connect** button. The **PC Panel Communication Status** displays the progress and communication status.

Note: If the connection to PC Panel is successful, the **Upload NFPA Requisite** and **View Upload Files** buttons are enabled under Upload NFPA Requisite.



- Click **OK** in the confirmation message.
- Click **Upload NFPA Requisite** button under **Upload NFPA Requisite**. The device maintenance information is uploaded from the fire panel and the **Device Maintenance Information** table displays the uploaded data as shown below.

Note: If the Device Maintenance Information is not uploaded, you cannot view the Uploaded Files.

[illegible]

8. Click the **Close** button to close the **Upload NFPA Requisites** dialog box.
9. Click the **Save to Database** button. The **Save confirmation** box appears.
10. Click **OK** to confirm.

Click the **Return to Main Screen** button to view the main screen.

Click **Prev** to go back to the **Notification and Approvals** dialog box.

Reports Menu

Configuration Data Report

Using the **Reports** option in FS-Tools, you can generate the configuration data report, which gives the configuration information of the input, output, and optional modules, and the fire alarm system settings. This report is generated as a *PDF* file. You can store the reports to maintain the configuration information of the fire panel at different times and dates. A printout of the configuration data report helps in manual verification of the fire alarm system settings.

To generate the report:

1. Select a customer record from the initial customer screen, using the **Find** option if necessary.
2. Choose **Reports > Configuration Data** in the initial customer screen in FS-Tools.

Fire Panel Configuration Report For 50 Pt Addr.

Customer Name: PaulContact Number: 2034847161

PANEL CONFIGURATION INFORMATION

Configuration Type: SavedConfiguration Date and Time: 6/14/2017 10:57:16 AM

SYSTEM CONFIGURATION

COMMUNICATOR SETTINGS

CENTRAL STATION

IPOTS-COM Installed:	True
Trouble Call Limit:	02
Test Time Interval:	12 Hours
Test Start Time:	07:00
Reporting Style:	Point

POTS Configuration

	PhoneLine 1	PhoneLine 2
PhoneLine Enabled:	True	True
Supervision Enabled:	False	False
TouchTone/Rotary:	Touch Tone	Touch Tone

GAIN Settings

Dialing Gain:	NORMAL
Reporting Gain:	NORMAL

Ethernet/Cellular Configuration

DHCP Enabled:	True
IP Address:	...
Gateway Address:	
Subnet Mask:	
Dns Address:	
Access Point Name:	
Supervision:	ALARMNET 2010 IP

PRIMARY

Communication Path	POTS
Communication Format	ADEMCO CONTACT ID
Account Code	159753
Phone Line Prefix	
Phone Number	2034847161
Location ID	9630
Central Station ID	1472

SECONDARY

Communication Path	POTS
Communication Format	SIA 8
Account Code	852014
Phone Line Prefix	
Phone Number	2034847161
Location ID	3641
Central Station ID	9764

6/14/2017 10:57:22AMPage 1 of 23

Note: You can generate the configuration report only for the configuration saved in the FS-Tools database. You cannot generate the report for *Factory Default* configuration.

By default, the configuration data report is stored in the C:\FS-Tools\Reports folder.

Central Station Report

Using the Reports option in FS-Tools, you can generate the central station report which prints the details of devices and their associated event codes. This report is displayed in a tabular format listing the Point troubles and their corresponding event codes. The report also displays the configured system event codes. This report can be generated as a *PDF* file and an *Excel* file.

Generate as PDF

1. Select a customer record from the initial customer screen. Use the **Find** option, if necessary.
2. Choose **Reports > Central Station Report > Export To PDF** in the initial customer screen in FS-Tools. The Central Station report for the selected customer is generated as a PDF file.

The screenshot shows a PDF document titled "John_10_13_2010_3_46_37 PM.pdf" in Adobe Reader. The report content is as follows:

Device Types - Event Codes Mapping For Central Station

Customer Information

Name : Paul Chadbourne

Address : 4 Yawkey Way MA Boston 02215

Contact Number : 617-267-9440

Panel Configuration Information

PANEL TYPE: 50 Pt. Addr.

Primary Central Station

Communication Format : ADEMCO CONTACT ID

Loop	Device Address	CS Address	Detector/Module	Device Type	Custom Label	Active	Restoral
1	1	1	Detector	SMOKE(PHOTO)		111	
1	2	2	Detector	SMOKE(PHOTO)		111	

Note: You can generate the central station report only for the configuration saved in the FS-Tools database. You cannot generate the report for Factory Default configuration.

By default, the central station report is stored in the C:\FS-Tools\ReportsAddressable\PDFs.

Generate as Excel File

1. Select a customer record from the initial customer screen. Use the **Find** option, if necessary.
2. Choose **Reports > Central Station Report > Export To Excel** in the initial customer screen in FS-Tools.
3. A central Station report for the selected customer is generated as a Excel file. By default, the configuration data report is stored in the C:\FS-Tools\ReportsAddressable\Excel Folder. Save the file where desired.

Primary Central Station								
	A	B	C	D	E	F	G	H
1	Primary Central Station							
2	Communication Format	ADEMCO CONTACT ID						
3								
4	Loop	Address	CS Address	Detector/Module	Type	CustomLabel	Active/Value	Restoral
5	1	1	1	Detector	SMOKE(PHOTO)		111	
6	1	2	2	Detector	SMOKE(PHOTO)		111	
7	1	3	3	Detector	SMOKE(PHOTO)		111	
8	1	4	4	Detector	SMOKE(PHOTO)		111	
9	1	7	7	Module(Input)	MONITOR		110	
10	1	8	8	Module(Input)	MONITOR		110	
11	1	9	9	Module(Input)	MONITOR		110	
12	1	10	10	Module(Input)	MONITOR		110	
13	1	11	11	Module(Input)	MONITOR		110	
Primary Central Station Secondary Central Station Primary System Event Codes Secondary System Event Codes								

Note: You can generate the configuration report only for the configuration saved in the FS-Tools database. You cannot generate the report for a *Factory Default* configuration.

NFPA Report

Record of Completion Report

Generate as PDF

1. Select a customer record from the initial customer screen, using the **Find** option if necessary.
2. Choose **Reports > NFPA Report > Record of Completion > Export to PDF** in the initial customer screen in FS-Tools.

The Record of Completion Report for the selected customer is generated as a PDF file.

By default, the Record of Completion Report data is saved to the C:\FS-Tools\ReportsAddressable\PDF folder.

The screenshot shows a PDF document titled "John Smith_8_8_2011 11_43_29 AM_8_8_2011 11_43_33 AM.pdf" in Adobe Reader. The document content is titled "Protected Site Information" and is divided into three sections:

Site Information	
Site Name :	XYZ Synderia
Address :	#12, 5th Main Road ,Commercial Street
Description of Property :	5 Story Building
Occupancy Type :	Residential

Property Representative	
Name of property representative :	David
Address :	#24, Langford Town
Phone :	980-778-9988
Fax :	56789055
Email :	david.k@xyz.com

Authority Having Jurisdiction Over This Property	
Name :	AHJ Having Jurisdiction over this prop
Address :	#45, Residency Road
Phone :	787-886-9876
Fax :	66778855
Email :	ahj.residency@xyz.com

Note: You can generate the Record of Completion report only for the configuration saved in the FS-Tools database. You cannot generate the report for Factory Default configuration.

Generate as Excel File

1. Select a customer record from the initial customer screen, using the **Find** option if necessary.
2. Choose **Reports > NFPA Report > Record of Completion > Export to Excel** in the initial customer screen in FS-Tools.

The Record of Completion Report for the selected customer is generated as an Excel file.

By default, the Record of Completion Report data is saved to the C:\FS-Tools\ReportsAddressable\Excel folder.

Record Of Completion NFPA Report	
Customer Name:	Paul Chadbourne
Panel Type :	50 Pt. Addr.
Protected Site Information	
Site	
Site Name :	Honeywell International Inc
Address :	39 Old Ridgebury Road # 12
Description of	Honeywell International Inc
Occupancy Type :	Office
Property Representative	
Name of property representative :	Chris Baldwin
Address :	1253 E Putnam Ave
Phone :	203-698-1790
Fax :	203-698-1799
Email :	chris.baldwin@gmail.com
Authority Having Jurisdiction Over This Property	
Authority having jurisdiction over this property :	William Broadman
Address :	573 Boston Post Rd

Note: You can generate the Record of Completion report only for the configuration saved in the FS-Tools database. You cannot generate the report for Factory Default configuration.

Generate as Word Document

1. Select a customer record from the initial customer screen, using the **Find** option if necessary.
2. Choose **Reports > NFPA Report > Record of Completion > Export to Word** in the initial customer screen in FS-Tools.

The Record of Completion Report for the selected customer is generated as a Word document.

By default, the Record of Completion Report data is stored in the C:\FS-Tools\ReportsAddressable\Word folder.

Paul_8_24_2012 8_51_16 AM_8_24_2012 8_53_04 AM [Compatibility Mode] - Microsoft Word

Home Insert Page Layout References Mailings Review View

Record Of Completion NFPA Report

Customer Name: Paul Chadbourne

Panel Type: 50 Pt. Addr.

Protected Site Information

Site Information

Site Name: Honeywell International Inc

Address: 39 Old Ridgebury Road # 12

Description of Property: Honeywell International Inc

Occupancy Type: Office

Property Representative

Name of property representative: Chris Baldwin

Address: 1253 E Putnam Ave

Phone: 203-698-1790

Fax: 203-698-1799

Email: chris.baldwin@gmail.com

Authority Having Jurisdiction Over This Property

Name: William Broadman

Address: 573 Boston Post Rd

Phone: 203-445-9989

Fax: 203-565-7766

Page: 1 of 13 Words: 2,070 Insert 100%

Note: You can generate the Record of Completion report only for the configuration saved in the FS-Tools database. You cannot generate the report for Factory Default configuration.

Inspection and Testing Report

Generate as PDF

1. Select a customer record from the initial customer screen, using the **Find** option if necessary.
2. Choose **Reports > NFPA Report > Inspection and Testing > Export to PDF** in the initial customer screen in FS-Tools.

The Inspection and Testing Report for the selected customer is generated as a PDF file.

The screenshot shows a PDF report generated from the FS-Tools application. The report is titled "John Smith_8_8_2011 11_43_29 AM_8_8_2011 11_49_11 AM.pdf" and is displayed in the Adobe Reader application. The report contains the following sections:

- General Information**
 - Date : Wednesday, August 03, 2011
 - Time : 3:33 PM
- Service Organization**
 - Name : XYZ Solutions
 - Address : #12, 5th Main Road ,Commercial Street
 - Representative : Christopher David
 - License No. : 123VGHHI99
 - Telephone : 567-998-7656
- Monitoring Entity**
 - Contact : Tom
 - Telephone : 876-887-9900
 - Monitoring Account Ref. No. : 5674456777889
- Approving Agency**
 - Contact : David
 - Telephone : 554-887-9876
- Service**

Note: You can generate the Inspection and Testing report only for the configuration saved in the FS-Tools database. You cannot generate the report for Factory Default configuration.

By default, the Inspection and Testing Report data is stored in the C:\FS-Tools\ReportsAddressable\PDF folder.

Generate as Excel File

1. Select a customer record from the initial customer screen, using the **Find** option if necessary.
2. Choose **Reports > NFPA Report > Inspection and Testing > Export to Excel** in the initial customer screen in FS-Tools.

The Inspection and Testing Report for the selected customer is generated as an Excel file.

Inspection and Testing NFPA Report	
Customer Name : Paul Chadbourne	
Panel Type :	50 Pt. Addr. Uploaded Date and Time 12/8/2017 10:19:58 AM
General Information	
Date :	12/1/2017 Time 11:57
Service Organization	
Name :	ABC Solutions
Address :	No 32, Boston Post Road
Representative :	Chris Baldwin
License No. :	123488977
Telephone :	203-998-7788
Monitoring Entity	
Contact :	Jim Kennedy
Telephone :	209-889-7788
Monitoring Account Ref. No. :	778966000
Approving Agency	
Contact :	William Kline

Note: You can generate the Inspection and Testing report only for the configuration saved in the FS-Tools database. You cannot generate the report for Factory Default configuration.

By default, the Inspection and Testing Report data is stored in the C:\FS-Tools\ReportsAddressable\Excel folder.

Generate as Word Document

1. Select a customer record from the initial customer screen, using the **Find** option if necessary.
2. Choose **Reports > NFPA Report > Inspection and Testing > Export to Word** in the initial customer screen in FS-Tools.

The Inspection and Testing Report for the selected customer is generated as a Word document.

Inspection and Testing NFPA Report

Customer Name : Paul Chadbourne

Panel Type : 50 Pt. Addr. Uploaded Date and Time : 12/8/2017 10:19:58 AM

General Information

Date : 12/1/2017 Time : 11:57

Service Organization

Name :	ABC Solutions
Address :	No 32, Boston Post Road
Representative :	Chris Baldwin
License No. :	123488977
Telephone :	203-998-7788

Monitoring Entity

Contact :	Jim Kennedy
Telephone :	209-889-7788
Monitoring Account Ref. No. :	778966000

Approving Agency

Contact :	William Kline
Telephone :	209-889-7788

Page: 1 of 10 Words: 1,354 Insert 100%


Note: You can generate the Inspection and Testing report only for the configuration saved in the FS-Tools database. You cannot generate the report for Factory Default configuration.

By default, the Inspection and Testing Report data is stored in the C:\FS-Tools\ReportsAddressable\Word folder.

Troubleshooting

Panel Connection Lost


Trouble: The following message is displayed when the connection is lost between the computer and fire panel.



Resolution: Check the serial port connection between the computer and the fire panel.

FS-Tools Failed to Download Data to Panel


Problem: The following message is displayed in FS-Tools cannot download data to fire panel.



Resolution: Check the power connection for the fire panel which might be turned off.

FS-Tools Failed to Upload Data from Panel


Problem: The following message is displayed when FS-Tools cannot upload data from fire panel.



Resolution: Check the power connection for the fire panel which might be turned off.

Verify Secret Code Request Denied

Trouble: The following message is displayed when the secret code verification fails and when the connection between the computer and fire panel fails.



Resolution: In the **Upload/Download** screen, use the **Set Secret Code at Panel** option to verify and if required, change the panel secret code.

Other Events

Problem: The troubleshoot data, uploaded from the fire panel into FS-Tools, displays the detector sensitivity data, and LED and piezo status.

Upload Information -> Troubleshoot Data

Detector Sensitivity Data

Loop No.	Detector No.	Detector Type	Sensitivity Level	%Obs / Temperature
1	1	HEAT DETECT	6	88(190 F)
1	3	SMOKE (ION)	5	1.50
1	5	SMOKE (ION)	5	1.50
1	8	SMOKE(PHOTO)	6	1.66
1	9	SMOKE (ION)	5	1.50
1	10	SMOKE (ION)	5	1.50
1	11	SMOKE (ION)	5	1.50
1	13	SMOKE (ION)	5	1.50

Print Detector Data

LED and Piezo Status

Fire Alarm

ACK

Alarm Silence

Drill

CO Alarm

Battery

Disabled

Communication

Maintenance

AC Power

Supervisory

Trouble

Ground

* Piezo Status : On

F1

F2

F3

F4

<< Prev

Resolution: Supervise the field wiring for each zone for open circuits, shorts, and ground faults. All the faults are visually and audibly annunciated.

Contact Us

Documentation Feedback

Your feedback helps us keep our documentation up-to-date and accurate. If you have any comments or suggestions about our online Help or printed manuals, you can email us.

Please include the following information:

- Product name and version number (if applicable)
- Printed manual or online Help
- Topic Title (for online Help)
- Page number (for printed manual)
- Brief description of content you think should be improved or corrected
- Your suggestion for how to correct/improve documentation

Send email messages to:

FireSystems.TechPubs@honeywell.com

Please note this email address is for *documentation feedback* only. If you have any technical issues, please contact Technical Services.

Technical Support

For technical assistance, please contact the Fire•Lite Technical Services department at 1-800-627-3473.

Index

A

ANN-80 35

ANN-ACC 35

ANN-Bus Address 35

ANN-ECC 35

ANN-LED 34

ANN-S/PG 34

B

Banner 32

C

Central Station 19, 22

Central Station Report 148

Clock 31

Combination Systems 137

Comm Panel ID 19

Communicator 19, 20

Compare Configuration 80

Configuration 19

 Central Station 19

 Communicator 19, 22

 Configuration Type 18

 Input/Output 24, 26

 NACs 26, 27, 28

Configuration Data 147

Connect/Disconnect to Panel 96

Contact 161

Customer 12, 13, 14, 15, 16

D

Database Backup 81

Daylight Savings Time 31

Delete Template 79

Detectors 50

Download 89

Download Password 78

E

Export 82

F

Function Keys 47

I

Import 84, 85

Installing/Uninstalling 2, 9

L

Last Configuration Date 88

M	Detectors 50, 56, 57, 65
Modules 59	Modules 59, 65, 68
N	System Requirements 9
NACs 26	System Settings 28
NFPA Report 149, 152	T
R	Troubleshooting 156, 157, 158, 159
Relays 24	U
Reports 102	Upload Information 74, 94
Inspection and Testing 124, 126, 127, 128, 130, 131, 133, 134, 135, 137, 138, 139, 140	History Data 75
Record of Completion 104, 105, 107, 109, 113, 115, 116, 118, 120, 121	System Status Data 76
Upload Information 142	Walktest Data 75
Restore Backup 81	V
Run 87	Verify Setup 69
S	W
Simulation 70	Write Access 86
SLC Loop 49	Z
	Zones 24



One Fire-Lite Place, Northford, CT 06472-1601 USA
USA - Phone: (203) 484-7161
Canada - Phone: (905) 856-8733
www.firelite.com

