

# Honeywell



## Velociti® Series

### MS-7AF Addressable Pull Station

Patented, U.S. Patent No. Des. 428,351; 6,380,846; Other Patents Pending

Document 9001-0010

156-3555-004

#### Description

The MS-7AF Addressable pull station is a non-coded, dual-action manual pull station with a key-lock reset feature. It provides Gamewell-FCI intelligent fire alarm control panels (FACP) with one addressable alarm initiating input. The addressable module is housed inside the pull station. The MS-7AF meets the ADAAG controls and operating mechanisms guidelines (section 4.1.3[13]), and the ADA requirement for a 5 lb. maximum pull force to activate the pull station. Operating instructions are molded into the pull station handle along with Braille text. Molded Terminal numbers are also present. Conforms to ANSI/UL Standard 38 and ULC Standard S528.

#### Ratings

Normal Operating Voltage:	24 VDC
Average Operating Current (LED Flash):	375 µA
Maximum Operating Current (LED On):	5 mA.
Temperature Range:	32°F to 120°F (0°C to 49°C)
Relative Humidity Range:	10% to 93% Non-condensing

#### Installation

The MS-7AF Addressable pull station can be surface mounted to an SB-10 or SB-I/O surface backbox or semi-flush mounted on a standard single-gang, double-gang or 4-inch (10.16 cm) square electrical box. The optional BG-TR trim ring can be used if the MS-7AF is to be semi-flush mounted.

#### Operation


To activate the dual-action pull station, push in and pull down on the handle. The word 'ACTIVATED' appears after the handle is pulled down. This will remain until the pull station is reset. The pull station includes one Single Pole, Single Throw (SPST) Normally Open (N/O) switch which closes upon activation of the pull station.

#### Resetting the Pull Station

1. Insert the key into the lock and rotate 1/4 turn counterclockwise.
2. Open the door until the handle returns to normal.
3. Close and lock the door.

**NOTE:** Closing the door automatically resets the switch to the 'Normal' position. Opening the door will not activate or deactivate the alarm switch.

#### Wiring



P0241-00

156-3555-004  
9001-0010



P0270-01

**MS-7AF  
Addressable Pull Station**

#### CAUTION

Do not detach the door of the pull station during installation. The door of the pull station cannot be reattached to the backplate after the backplate has already been installed onto an electrical box.

#### CAUTION

Install the Gamewell-FCI MS-7AF addressable pull station in accordance with these instructions, applicable NFPA standards, national and local Fire and Electrical codes and the requirements of the AHJ (Authority Having Jurisdiction). Regular testing of the devices should be conducted in accordance with the appropriate NFPA standards. Failure to follow these directions may result in failure of the device to report an alarm condition. Honeywell is not responsible for devices that have been improperly installed, tested or maintained.

#### ADA Compliance

For ADA compliance, if the clear floor space only allows forward approach to an object, the maximum forward reach height allowed is 48 inches (121.92 cm). If the clear floor space allows parallel approach by a person in a wheelchair, the maximum side reach allowed is 54 inches (137.16 cm).

## Setting the MS-7AF Address

The MS-7AF Addressable pull station is factory preset with address '00.' Set the address for the pull station by turning the rotary address switches on the addressable module mounted inside the pull station. Only one device per address is allowed. Multiple modules may not be set to the same address on the Signaling Line Circuit. Once the address is set, record it in the space provided on the product ID label located inside the pull station.

