

## Login to INNcontrol 3

Some features and controls in INNcontrol 3 are password protected and require a user login. User accounts are setup during installation. Contact your IT department for more information on your INNCOM INNcontrol 3 user account. You may also contact INNCOM Technical Support for assistance (Tel: +1.860.739.4468, Option #2, [support@inncom.com](mailto:support@inncom.com))

